



Philips
Wireless hi-fi headphones

Adjustable fit
Infrared transmission

SHC2000



IR wireless

For TV

These full-size rechargeable infrared cordless headphones combine quality and convenience for either TV or music enjoyment in your home.

You'll forget you're wearing them!

- Lightweight design improves comfort for prolonged use.
- Self-adjusting inner headband ensures a comfortable fit

The perfect wireless listening experience

- High-frequency RF ensures clear and sharp reception
- ALC helps prevent audible distortion of input signals

Always ready to go

- IR wireless transmission provides freedom of movement
- Reduces costs by using rechargeable batteries

PHILIPS

Wireless hi-fi headphones
Adjustable fit Infrared transmission

Specifications

Sound

- Acoustic system: closed
- Magnet type: Ferrite
- Frequency response: 18–20,000 Hz
- Sensitivity: 108 dB
- Speaker diameter: 32 mm

Tuner/Reception/Transmission

- Effective range: 7 m
- Carrier frequency range: 2.3 (L) - 2.8 (R) MHz
- Channel separation: >30 dB
- Modulation: FM

Convenience

- Operating time: +/- 15 hours

Power

- Power supply headphone: 2 x 1.5 V NiMH R03/AAA
- Power supply transmitter: AC/DC adapter 12 V/

200 mA

Inner Carton

- Gross weight: 5.0852 kg
- Inner carton (L x W x H): 42.9 x 30.6 x 24.2 cm
- Net weight: 3.666 kg
- Tare weight: 1.4192 kg

Outer Carton

- Gross weight: 11.0365 kg
- Outer carton (L x W x H): 44.5 x 32.3 x 51.5 cm
- Net weight: 7.332 kg
- Tare weight: 3.7045 kg

Packaging dimensions

- Packaging dimensions (W x H x D): 20.7 x 10 x 22.5 cm
- Gross weight: 0.7867 kg
- Net weight: 0.611 kg
- Tare weight: 0.1757 kg

SHC2000/00

Highlights

Lightweight design



The durable, lightweight quality materials of these Philips headphones enhance comfort for extended wear.

Self-adjusting inner headband

The inner headband of these Philips headphones makes it easy to obtain a perfect fit for your head. The mechanism adjusts automatically for comfort.

High-frequency modulation

Using very high frequency modulation (RF) for the transmission link ensures sharp, clear reception.

Automatic Level Control (ALC)

This smart electronic circuit ensures that the audio input level is automatically adjusted to the right level, preventing distortion and preserving your listening enjoyment.

IR wireless transmission

IR wireless transmission allows you to be free from the hassles of cables.

Rechargeable system

The headphone set incorporates facilities for recharging the batteries.



Issue date 2014-03-10

Version: 5.0.7

12 NC: 9082 100 07812
EAN: 87 10895 95765 6

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com