



Philips  
Mobile Phone

362

CT3621

## Let me Dazzle you!

Look and performance, a perfect convergence: the Philips 362 camera phone. Endowed with a multi-shot digital camera, super bright light and progressive 4x digital zoom, it's ready to capture your every moment.

### Share digital photos

- Infrared for close-range information exchange
- MMS (Multimedia Messaging Service)
- TV SlideShow

### Designed for snapshots

- Super-bright flash
- Digital continuous zoom for better pictures
- Integrated VGA digital camera
- Multi-shot for continuous pictures

### Connect and enjoy

- WAP
- Java 2.0 technology
- Embedded games for fun with your phone
- E-mail to stay connected wherever you are

# PHILIPS

# Highlights

## Integrated VGA digital camera

The integrated digital camera with VGA resolution (640x480 pixels) allows you to take high-quality pictures anytime, anywhere with your phone, then send them via MMS or email, or store the pictures in your phone's memory.

## Super bright torch light

'Super-bright flash is a light generated by LED to take pictures in low light conditions, such as night. Manually activate and deactivate the super-bright flash by pressing and releasing the "+" or "-" volume side key (super-bright flash is automatically de-activated once the photo has been taken).

## Continuous zoom

Continuous digital zoom lets you easily and smoothly zoom the picture in and out from the original, composing better and more meaningful pictures by capturing the right detail at the right distance from the overall scene.

## Multi-shot

Multi-shot for continuous pictures allows you to use a single click to take a sequence of

photos to capture movement. Select continuous shooting: time and interval.

## MMS messaging

MMS (Multimedia Messaging Service) allows you to use your mobile phone to send and receive pictures, video, and audio files with your text messages.

## Infrared

Infrared is the simplest wireless technology for information exchange at close range, allowing easy sharing of images, backgrounds, songs, and phonebook contacts with friends and family and enabling wireless access to the internet through your PC.

## TV SlideShow

TV SlideShow allows you to display pictures from your phone's photo album directly on a TV screen for the fun of sharing pictures from your phone's camera with friends and family. Simply connect your mobile phone and TV with the TV Link accessory to run an automatic or manual slideshow.

## Java 2.0

Java 2.0 technology allows you to enhance and personalize your phone with new games and applications simply by downloading them.

## Embedded games

Embedded games use the bright color screen and keypad to turn your mobile phone into a game station. Simply go to the dedicated submenu to start playing your favorite game.

## WAP

Wireless Application Protocol (WAP) version 1.2.1 is a standardized way for a mobile phone to talk to a server in the mobile phone network to connect your phone to WAP-enabled web sites, allowing you to access comprehensive information whenever you need it.

## E-mail

Electronic mail is another way to stay connected to your contacts with your mobile phone by sending and downloading e-mails as easily as if you were in front of your PC.



# Specifications

## Picture/Display

- Main Display Resolution: 128x160 pixels
- Main Display Technology: CSTN
- Main Display Colors: 65536
- Brightness: 120 cd/m<sup>2</sup>
- Lines of text: 8
- Diagonal screen size: 1.8

## Still Picture Capturing

- Camera: Integrated
- Picture resolution: VGA (640x480)
- Flash: built-in
- Digital zoom: Continuous up to x4
- Picture file format: JPEG
- Picture Mode: Normal, Night mode, Self-timer mode, Multi-shot
- Picture quality: Normal, Fine, Superfine
- Special effects preview mode: Grey scale, Sepia, Edge, Digital, Embossed, Negative color
- Sensitivity: min 5 lux
- Preview frame rate: 15 frames/second
- Image sensor type: CMOS

## Still Picture Playback

- Picture Compression Format: BMP, GIF, GIF (87a & 89a), JPEG
- Rotation: 90 degree steps
- Picture Enhancement: Frames & Icons
- Slide show

## Storage Media

- Built-in memory (RAM): 16
- Memory management: Memory status, Dynamic memory allocation
- User memory: 4 MB

## Connectivity

- Modem Capabilities: CSD (Voice, Data), GPRS, SMS
- Headset: Via bottom connector
- PC Link: USB 1.1

- Serial connections: USB-Bottom connector cable
- Synchronisation PC organizer: Lotus Notes, MS Outlook
- Wireless connection: Infrared

## Network Features

- GPRS (Rx+Tx): Class 10 (4+2), Class B
- Messaging: Concatenated SMS (Long SMS), E-mail, EMS / release 4, MMS, Multimedia Message Service, Predefined messages (SMS, MMS), Quick SMS, SMS CB (Cell Broadcast), SMS (Short Message Service), SMS multi-target, QQ instant messaging
- Services: OTA provisioning (WAP, MMS), SIM Toolkit / Release 99, WAP 1.2.1, WAP Browser Teleca2.0
- Voice Codec: FR/EFR/AMR
- GSM band: 900, 1800 MHz

## Power

- Battery Capacity: 750 mAh
- Battery Type: Lithium-ion
- Standby time: up to 400 hrs
- Talk time: up to 6 hrs
- Charging time: less than 2.5 hours hour(s)
- Battery saving manager: Auto switch on/off

## Convenience

- Ease of Use: Hands free mode, Hot Keys, Keypad Lock, Screen Saver Digital Clock, Vibra Alert, Softkeys
- Call Management: Call Cost, Call Counters, Call Forwarding, Call on Hold, Call Time, Call Waiting\*, Caller ID\*, Conference Call, Emergency Call, Explicit Call Transfer, Microphone mute, Missed Calls, Multi-party call, Received Calls
- Buttons and controls: 4-way navigation key and enter, Customized hot key
- Clock/Version: Analogue, Digital, International clock
- Multimedia: Foto Talk
- Speech Recognition: Conversation Recording,

- Voice Command, Voice Dial, Voice Recognition, Long voice memo
- Embedded Games: 4
- Games and applications: Agenda, Alarm Clock, Calculator, Calendar, Java MIDP 2.0, Lunar Calendar, International converter, Voice reminder if appointment
- Ease To Experience: Demo Mode
- Ease of Navigation: Animated Color Matrix
- Text input: T9, T9 user database, Character counter
- Personal Info Management: Smart Phonebook, Vcard Exchange, Safeguard, International clock
- Personalisation/Customization: Downloadable Animated GIF, Downloadable Java Applications, Downloadable Picture, Downloadable Ringtones, Fotocall, Screen Saver, Wallpaper

## Sound

- Ringers: Polyphonic (16 tones)

## Audio Capturing

- Voice recording: Yes, AMR

## Audio Playback

- Audio supported formats: AMR, Midi

## Audio Recording

- Recording time: upto 60 seconds

## Dimensions

- Handset Color: Dazzling Silver, Luminous Black
- Form Factor: Candy bar
- Antenna: Integrated
- Handset dimensions: 100 x 45 x 18 mm
- Handset volume: 75 cc
- Handset weight: 83 g

## Green Specifications

- Lead-free soldered product

# Specifications

## Accessories

- Standard Package Includes: Battery, Charger, Handset, International Guarantee, SAR information leaflet, User Manual
- Optional accessories: Car cradle, Carry case,

Cigarette lighter adapter, Deluxe FM headset, Deluxe headset, Necklace, Stereo FM handsfree headset, TV Link, Universal car kit, USB data cable + PC software



Issue date 2023-12-26

Version: 3.0.5

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)