

Portable CD player

AX2481

Jogproof

With Digital FM tuner

The irresistibly classic AX2481 CD player with LCD display lets you savor smooth, skip-free music. Its stylish form will appeal to all music lovers and it also comes with FM tuner with 20 presets for a super music experience on the go.

Jogproof

- 45-second Electronic Skip Protection

Enhanced bass performance

- Dynamic Bass Boost

Enjoy your FM music wherever you go

- Digital FM tuner with 20 presets

Enjoy all kinds of discs

- Plays CD, CD-R and CD-RW discs



PHILIPS

Portable CD player

AX2481/17

Technical specifications

Sound

- D/A converter: 1-bit
- Frequency response: 20 - 20 000 Hz
- Signal to noise ratio: > 80 dB
- Sound Enhancement: Dynamic Bass Boost
- Output Power (RMS): 2 x 3 mW
- Volume Control: Digital
- Acoustic Feedback

Audio Playback

- Disc Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes:
30-Track Programmable,
Fast Forward/Backward, Hold, Repeat Play,
Resume Playback from stop, Shuffle Play, Scan
- Electronic Skip Protection(CD): 45 sec

Tuner / Reception / Transmission

- Tuner Bands: FM Stereo
- Frequency range: 87.5 - 108 MHz
- Station presets: 20
- Auto digital tuning

Connectivity

- DC in: 4.0 mm, 4.5V, centre +
- Headphone: 3.5 mm
- Line-out: 3.5 mm

Convenience

- Display Type: LCD
- Indications:
battery status, Cd functions, DBB, ESP, time,
track, frequency, pre-set station

Accessories

- Headphones (AY3805)
- Included Accessories: User Manual

Dimensions

- Housing: Heat Resistant Body, Lenticular Sheet
- Master carton dimensions (WxHxD):
8.5 x 13.6 x 9.2 inch
- Master carton quantity: 3
- Master carton weight: 1.8 kg
- Packaging dimensions (WxHxD):
8 x 12 x 2.7 inch
- Packaging type: Clamshell
- Product dimensions (WxHxD):
5.5 x 1 x 5.5 inch
- Product weight: 0.55 lbs

Power

- Battery Playing Time CD: 20
- Battery Type: AA, LR6, UM3

Product highlights

Electronic Skip Protection

Electronic Skip Protection (ESP) is an intelligent electronic buffer that guarantees uninterrupted music listening. Music is constantly fed into the player's memory buffer during playback, allowing you to continue to experience uninterrupted sound in the event of knocks, shakes or jolts to the set - accidentally or during sports. When shocks occur, music is released from the buffer while the laser promptly refocuses to the point at which the shock occurred and recommences playing to refill the buffer. ESP ensures smooth, skip-free music listening on your CD player while on the move!

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

CD-Rewritable compatible

CD-Rewritable compatible means that your audio set can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players. The laser pick-up and CD decoder circuitry of CD-RW compatible players are specially designed to read the special audio CD-RW phase change recording layer, ensuring you can always play your home-recorded discs on your audio CD system.

UPC: 0 37849 95606 9 (single)
1 00 37849 95606 6 (masterpack)

Date of issue 2005-07-04
Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.
© 2005 Koninklijke Philips Electronics N.V.
All rights reserved.

www.philips.com

