



Philips
USB power bank

27000 mAh

USB A & USB C charging ports
QC 3.0 and PD
White

DLP1925CW



Powerful power bank

with a portable back-up power pack

Have power wherever and whenever you need it 30,000 mAh big capacity for up to more than 1 full charge. 3 USB ports with USB-A and USB-C. Fast charge your device with USB-C PD3.0 Max 20W or USB-A port with QC3/0 Max 18W output.

Superior Charging Design

- Smart protection against overheat, overvoltage & overcurrent
- Quick Charge technology to optimize charging speed
- 50% charge in 30 minutes
- Charging using USB-C Programmable Power Supply (PPS)
- 3 USB ports charge three devices simultaneously

Portable power

- Recharge your devices multiple times on the go
- Works anywhere - great when you're not near a power source
- Fast charge with USB-C PD3.0 20W or USB-A with QC3.0 18W

Confirm operation at a glance

- LCD display for power indication

PHILIPS

USB power bank
27000 mAh USB A & USB C charging ports, QC 3.0 and PD, White

DLP1925CW/40

Specifications

Accessories

- User Manual: User Manual
- Cables: USB C cable

Power

- Output: USB & Type-C 5V/3A
- Power input: USB C \ Micro USB 5V/2A
- Battery Capacity: 30,000mAh 111Wh

Outer Carton

- Number of consumer packagings: 2
- GTIN: 1 48 95229 14271 5



Packaging dimensions

- Number of products included: 1
- EAN: 48 95229 14271 8

Product dimensions

- Product dimensions (W x H x D):
7.2 x 14.2 x 4.09 cm

Inner Carton

- Number of consumer packagings: 1
- GTIN: 2 48 95229 14271 2

Highlights

LCD display for power status

LCD display for power indication

Programmable Power Supply PPS

PPS (Programmable Power Supply) is a standard for fast charging technology for USB-C devices. This technology adjusts the voltage and current in real-time, depending on a device's charging status, feeding it with maximum power. A smart way to safely reduce charging time.

Smart Protection

Smart protection against overheating, overvoltage and overcurrent

Fast charge USB-C or USB-A

Fast charge your device with USB-C PD3.0 Max 20W or USB-A port with QC3.0 Max 18W output



Issue date 2023-12-16

Version: 1.0.2

12 NC: 8670 001 92541
EAN: 48 95229 14271 8

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com