



#### USB power bank

- 27000 mAh
- USB A & USB C charging ports
- QC 3.0 and PD
- White

DLP1925CW/40

## Powerful power bank

with a portable back-up power pack

Have power wherever and whenever you need it 30,000 mAh big capacity for up to more than 1 full charge. 3 USB ports with USB-A and USB-C. Fast charge your device with USB-C PD3.0 Max 20W or USB-A port with QC3.0 Max 18W output.

### Benefits

#### Superior Charging Design

- Charging using USB-C Programmable Power Supply (PPS)
- Quick Charge technology to optimize charging speed
- Smart protection against overheat, overvoltage & overcurrent
- 3 USB ports charge three devices simultaneously
- 50% charge in 30 minutes

- Works anywhere - great when you're not near a power source
- Recharge your devices multiple times on the go
- Fast charge with USB-C PD3.0 20W or USB-A with QC3.0 18W

#### Confirm operation at a glance

- LCD display for power indication

#### Portable power

### Features

#### LCD display for power status

LCD display for power indication

**PHILIPS**

### Programmable Power Supply PPS

PPS (Programmable Power Supply) is a standard for fast charging technology for USB-C devices. This technology adjusts the voltage and current in real-time, depending on a device's charging status, feeding it with maximum power. A smart way to safely reduce charging time.

### Smart Protection

Smart protection against overheating, overvoltage and overcurrent

### Fast charge USB-C or USB-A

Fast charge your device with USB-C PD3.0 Max 20W or USB-A port with QC3.0 Max 18W output

## Specifications

[field not found 'disclaimer\_text']

### Accessories

User Manual	User Manual
Cables	USB C cable

### Power

Output	USB & Type-C 5V/3A [USB-C output: 5V/3A, 9V/2.22A, 12V/1.5A (PD20W) USB-A1/A2 output: 5V/2.1A, 9V/2A, 12V/1.5A (QC18W) Total max.: 5V/3A]
Power input	USB C \ Micro USB 5V/2A [Micro USB input: 5V/2A, 9V/2A USB-C input: 5V/2A, 9V/2.22A]
Battery Capacity	30,000mAh 111Wh

### Outer Carton

Number of consumer packagings	2
-------------------------------	---

GTIN	1 48 95229 14271 5
------	--------------------

### Packaging dimensions

Number of products included	1
EAN	48 95229 14271 8

### Product dimensions

Height	14.2 cm
Width	7.2 cm
Depth	4.09 cm

### Inner Carton

Number of consumer packagings	1
GTIN	2 48 95229 14271 2



data subject to change  
2023, December 15

Version: 1.0.2  
EAN: 4895229142718

© 2023 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)