



Philips  
USB power bank

**27000 mAh**

USB A & USB C charging ports  
QC 3.0 and PD  
Black

**DLP1925CB**



## Powerful power bank

with a portable back-up power pack

Have power wherever and whenever you need it 30,000 mAh big capacity for up to more than 1 full charge. 3 USB ports with USB-A and USB-C. Fast charge your device with USB-C PD3.0 Max 20W or USB-A port with QC3/0 Max 18W output.

### Superior Charging Design

- Smart protection against overheat, overvoltage & overcurrent
- Quick Charge technology to optimize charging speed
- 50% charge in 30 minutes
- Charging using USB-C Programmable Power Supply (PPS)
- 3 USB ports charge three devices simultaneously

### Portable power

- Recharge your devices multiple times on the go
- Works anywhere - great when you're not near a power source
- Fast charge with USB-C PD3.0 20W or USB-A with QC3.0 18W

### Confirm operation at a glance

- LCD display for power indication

# PHILIPS

USB power bank  
27000 mAh USB A & USB C charging ports, QC 3.0 and PD, Black

DLP1925CB/40

# Specifications

## Accessories

- User Manual: User Manual
- Cables: USB C cable

## Power

- Output: USB & Type-C 5V/3A
- Power input: USB C \ Micro USB 5V/2A
- Battery Capacity: 30,000mAh 111Wh

## Outer Carton

- Number of consumer packagings: 2
- GTIN: 1 48 95229 14270 8



## Packaging dimensions

- Number of products included: 1
- EAN: 48 95229 14270 1

## Product dimensions

- Product dimensions (W x H x D):  
7.2 x 14.2 x 4.09 cm

## Inner Carton

- Number of consumer packagings: 1
- GTIN: 2 48 95229 14270 5

# Highlights

## LCD display for power status

LCD display for power indication

## Programmable Power Supply PPS

PPS (Programmable Power Supply) is a standard for fast charging technology for USB-C devices. This technology adjusts the voltage and current in real-time, depending on a device's charging status, feeding it with maximum power. A smart way to safely reduce charging time.

## Smart Protection

Smart protection against overheating, overvoltage and overcurrent

## Fast charge USB-C or USB-A

Fast charge your device with USB-C PD3.0 Max 20W or USB-A port with QC3.0 Max 18W output



Issue date 2023-11-20

Version: 1.0.2

12 NC: 8670 001 92539  
EAN: 48 95229 14270 1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)