

PHILIPS

Superior brightness,
a safer drive

Ultinon Pro7000 SI

Type of lamp: W5W

12 V, 4000 K Warm White

Advanced automotive system

2+1-year warranty

11961WU70X2



Enjoy superior brightness for a safer drive

Superior brightness, a safer drive

For unmatched visual comfort and safer driving, choose Philips Ultinon Pro7000 LED signalling bulbs. In exterior or interior applications, their vibrant colours and warm, white light instantly improve driver visibility and well-being.

Superior visibility

- Signal your intent with brighter exterior lighting
- Ergonomic design with three-LED array

High-end, stylish signalling

- Upgrade your lights, upgrade your style

Performance made to last

- Enhanced lifetime of up to 5,000 hours
- HeatShield ensures durable performance

Simple plug-and-play replacement

- Easy to install and compatible with most car models
- Electrical compatibility with most vehicles

Ultinon Pro7000 SI

Superior brightness, a safer drive

Highlights

Powerful brightness

Signalling the intended movement of your vehicle is vital to your safety. To avoid collisions, other people have to know what you're doing. And when poor weather reduces visibility, the need for bright and vibrant signalling becomes even greater. Philips Ultinon Pro7000 LED signalling lights provide you with bright, warm-white light up to 4000 K for positioning and interior lighting. Your car says a lot about you, so make a style statement with Philips LED signalling lights.

Uniform light distribution

Whether it's for sidelights, glove compartments or interior lighting, the Philips Ultinon Pro7000 LED gives you uniform light distribution. Its wide angle ensures that the light is projected where you need it.

Elegant LED light

While the main goal of exterior lighting is to help you see and be seen, there's no reason why you shouldn't look good at the same time. If you want to upgrade your style without buying a newer car, replacing your exterior lighting with Philips Ultinon Pro7000 LED lights is a smart way to spend your money.

Lifetime of up to 5,000 hours

You want bright, stylish car lights but you don't want to keep replacing failed lamps. That's a major weakness of conventional bulbs — the

more powerful the light, the shorter its lifespan. Even at a higher light intensity, LEDs last much longer. Philips Ultinon Pro7000 LED lights are built to last. Due to features such as high-end LED technology and advanced heat-management systems, they last for up to 5000 hours of operation and are covered by a 3-year warranty*.

Good at handling heat

With HeatShield technology, Philips Ultinon Pro7000 T10 bulbs are resistant to high temperatures even when installed next to headlight bulbs. Made with a special composite material, they can endure any thermal challenge and still offer high performance.

Ready, steady, installed!

Enjoy the plug-and-play experience: the Philips Ultinon Pro7000 comes with standard caps and is polarity-free, so replacement is quick and easy.

Electrical compatibility with most vehicles

LED retrofit and conventional bulbs differ from one another in terms of wattage, composition and power consumption. Replacing your conventional bulbs with other LEDs may prove problematic. Philips Ultinon Pro7000 bulbs are electrically compatible with most cars. Additional adapters are available as accessories for troubleshooting if needed. We sell a complete solution.

LUM11961WU70X2/10

Specifications

Marketing specifications

Product highlight: Automotive Grade LED
Powerful brightness Uniform light distribution
Expected benefits: Brighter, elegant signals

Product description

Application: Interior lights, front side/position lights, number plate, 3rd brake light, side indicators

Base: W21 x 9.5d

Designation: W5 W LED White 11961 WU70 12 V X2

Designation LED Type: LED-T10 [≈W5 W]

ECE certification: NO

Range: Ultinon Pro7000

Technology: LED

Type: W5W

Voltage: 12 V

Lifetime

Life time: 5000 hrs

Light characteristics

Lumens: 90

Colour temperature: 4000 K

Electrical characteristics

Voltage: 12 V

Wattage: 0.87 W

Ordering information

Order entry: 11961WU70X2

Ordering code: 02289930

Logistic data

Ordering code: 11961WU70X2

EAN1: 8719018022899

EAN3: 8719018022905

Packaging Data

EAN1: 8719018022899

EAN3: 8719018022905

Packaging type: X2

Packed product information

Length: 7,0 cm

Width: 2,5 cm

Height: 11,5 cm

Pack Quantity: 2 pcs

MOQ (for professionals): 10 packs

Gross weight per piece [g]: 24 g

Outer pack information

Length: 19,5 cm

Width: 15,5 cm

Height: 8,5 cm

Gross weight [kg]: 0.30 kg

© 2025 Koninklijke Philips N.V.
All Rights reserved.

Issue date 2025-02-28
Version: 3.3.1

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

EAN: 87 19018 02289 9

www.philips.com



* *2-year standard warranty + 1-year extended. Visit philips.com/auto-warranty to know more about our warranty policy

* Non-ECE compliant