

# PHILIPS

Superior brightness,  
a safer drive

Ultinon Pro7000 SI

Type of lamp: W21W

12/24 V, 6000 K Cool White

Advanced automotive system

2+1-year warranty

11065CU70X2



## Enjoy superior brightness for a safer drive

### Superior brightness, a safer drive

For unmatched visual comfort and safer driving, choose Philips Ultinon Pro7000 LED signalling bulbs. In exterior applications, their vibrant colours and crisp, white light instantly improve driver visibility and well-being.

#### **Superior visibility for safer driving**

- Signal your intent with brighter exterior lighting
- Instant safety information for other drivers
- Ergonomic design with 360° beam pattern

#### **High-end, stylish signalling**

- Upgrade your lights, upgrade your style

#### **Performance made to last**

- Enhanced lifetime of up to 5,000 hours
- Aluminium heatsink to dissipate heat more efficiently

#### **Simple plug-and-play replacement**

- Easy to install and compatible with most car models
- Electrical compatibility with most cars and trucks
- Easy to install on your car

## Highlights

### Powerful brightness

Signalling the intended movement of your vehicle is vital to your safety. To avoid collisions, other people have to know what you're doing. And when poor weather reduces visibility, the need for bright and vibrant signalling becomes even greater. Philips Ultinon Pro7000 LED signalling lights provide powerful brightness with 15 LEDs for your indicators. They will help you to see and be seen better, warning other drivers of your movements, which is vital for them to react sooner. The more you see or are seen, the safer your drive will be!

### Instant-on technology

Compared to incandescent lamps, the Philips Ultinon Pro7000 LEDs light up instantly to ensure that other drivers can react faster, keeping you safer.

### Uniform light distribution

For your turn indicator, reversing, rear fog and brake lights, the Philips Ultinon Pro7000 LED gives you uniform light distribution. Its 360° angle ensures that the light is projected where you need it. Not only can you see more of the road, but other drivers can also see more of you.

### Elegant LED light

While the main goal of exterior lighting is to help you see and be seen, there's no reason why you shouldn't look good at the same time. If you

want to upgrade your style without buying a newer car, replacing your exterior lighting with Philips Ultinon Pro7000 LED lights is a smart way to spend your money.

### Lifetime of up to 5,000 hours

You want bright, stylish car lights but you don't want to keep replacing failed lamps. That's a major weakness of conventional bulbs — the more powerful the light, the shorter its lifespan. Even at a higher light intensity, LEDs last much longer. Philips Ultinon Pro7000 LED lights are built to last. Due to features such as high-end LED technology and advanced heat-management systems, they last for up to 5000 hours of operation and are covered by a 3-year warranty\*.

### Super-robust lamps made with aluminium

When operating, LEDs generate heat which reduces their brightness and overall lifespan. Philips Ultinon Pro7000 LED lights feature an aluminium heatsink, which dissipates heat much faster than the conventional plastic base used by low-cost, inferior-quality bulbs. That makes our lamps more robust and longer lasting.

### Ready, steady, installed!

Enjoy the plug-and-play experience: Philips Ultinon Pro7000 LED lights use the same standard caps as the conventional lights on your

car, enabling you to upgrade with no modification needed, so replacement is quick and easy.

### Electrical compatibility with most cars and trucks

LED retrofit and conventional bulbs differ from one another in terms of wattage, composition and power consumption. Replacing your conventional bulbs with other LEDs may prove problematic. Thanks to the built-in constant IC driver, Philips Ultinon Pro7000 bulbs work within 9-32 volt systems and are electrically compatible with most cars and trucks. Canbus adapters are available as accessories for troubleshooting if needed. We sell a complete solution.

### Polarity-free design

Enjoy the plug-and-play experience: the Philips Ultinon Pro7000 comes with polarity-free design, so you don't need to worry about polarity during installation. It will save you time and make installation easier.

# Ultinon Pro7000 SI

Superior brightness, a safer drive

LUM11065CU70X2/10

## Specifications

### Marketing specifications

**Product highlight:** Polarity-free Automotive Grade LED Powerful brightness Uniform light distribution

**Expected benefits:** Brighter, elegant signals

### Product description

**Application:** Reversing lights, rear and front turn indicators, brake lights, rear fog lights for 12 and 24 V vehicles

**Base:** Universal wedge base

**Designation:** W21 W LED White 11065 CU70 12/24 V X2

**Designation LED Type:** LED-WHITE [≈W21 W]

**ECE certification:** NO

**Range:** Ultinon Pro7000

**Technology:** LED

**Type:** W21W

**Voltage:** 12V + 24V V

### Lifetime

**Life time:** 5000 hrs

### Light characteristics

**Lumens:** 340 lm (12 V) 420 lm (24 V)

**Colour temperature:** 6000 K

### Electrical characteristics

**Voltage:** 12/24 V

**Wattage:** 2.6 W (12 V) 3.3 W (24 V)

### Ordering information

**Order entry:** 11065CU70X2

**Ordering code:** 02259230

### Logistic data

**Ordering code:** 11065CU70X2

**EAN1:** 8719018022592

**EAN3:** 8719018022608

### Packaging Data

**EAN1:** 8719018022592

**EAN3:** 8719018022608

**Packaging type:** X2

### Packed product information

**Length:** 7,0 cm

**Width:** 2,5 cm

**Height:** 11,5 cm

**Pack Quantity:** 2 pcs

**MOQ (for professionals):** 10 packs

**Gross weight per piece [g]:** 40 g

### Outer pack information

**Length:** 19,5 cm

**Width:** 15,5 cm

**Height:** 8,5 cm

**Gross weight [kg]:** 0.46 kg

