

PHILIPS

Quick, easy
installation

Ultinon Access

Type of lamp: H7, H18

Direct-fit LED bulb

Compact design

6000 K cool white light

11972U2500C2



Upgrade. Drive. Enjoy.

Quick, easy installation

Upgrade your vehicle's headlights with the Philips Ultinon Access LED range. These bulbs are as quick and easy to install as halogen lamps! Enhance your lighting and enjoy the latest LED technology for your car.

Quick, easy installation

- Plug-and-play installation

Better light performance

- Better light-beam performance than halogen

Reliable Philips quality

- Compliant with automotive standards
- Long-lasting performance

Highlights

Plug-and-play installation

With Philips Ultinon Access LED bulbs, installation is so quick and easy that retrofitting them is child's play. There's no need for compatibility checks or adapter rings: Philips Ultinon Access LED bulbs come with an ultra-compact body and an integrated IEC 60061 compatible base. Their direct-fit design features the same footprint as halogen bulbs, enabling straightforward installation in tight spaces. They fit easily into vehicles equipped with H7/H18-type bulbs and ensure broad compatibility with most vehicle models*

Beam outperforms halogen

Philips Ultinon Access LED bulbs are designed to offer a better light beam performance than halogen bulbs in a compact, universal design. Using the latest innovations in LED technology, they provide the same luminous flux as standard ECE halogen bulbs but significantly improve beam performance using less energy. Philips Ultinon Access LED bulbs provide drivers with better on-road vision, making it easier to spot obstacles and drive more safely.

Compliant with automotive standards

Technologically advanced, Philips lighting has been renowned in the automotive industry for over 100 years. We are aware that the performance of our products depends on their compatibility with the demands of today's automotive environment, so we design our products as closely as possible to industry standards. Our Philips Ultinon Access LED bulbs comply with EMI standards for electromagnetic interference. Precision-engineered to withstand the rigours of modern automotive life, our bulbs won't disrupt the operation of other vehicle components.

Long-lasting performance

Philips Ultinon Access LED bulbs are rigorously tested and checked to ensure long-term durability and long-lasting performance. Our range offers up to three times the life of a comparable halogen bulb plus homogeneous light throughout the bulbs' lifespan. The Philips warranty policy covers Philips Ultinon Access LED bulbs. Visit [Philips.com/auto-warranty](https://philips.com/auto-warranty) to learn more and sign up for an extended warranty**. Enjoy the best of today's technology with Philips Ultinon Access LED bulbs.

Specifications

Marketing specifications

Product highlight: Direct-fit LED bulb

Expected benefits: Simple and fast installation

Product description

Application: High Beam, Low Beam, Fog

Base: PX26d/PY26d-1

Designation: LED H7/H18 11972 12 V U2500 C2

Designation LED Type: [≈H7], [≈H18]

Operating Temperature: -40°C/+85°C

Range: Ultinon Access

Technology: LED

Type: H7, H18

ECE R37 certification: No

ECE R10 certification

Polarity free

Lifetime

Life time: 1500 hours

Light characteristics

Colour temperature: 6000 K

Lumens [lm]: 1600

Electrical characteristics

Wattage: 16 W

Voltage: 12 V

Ordering information

Order entry: 11972U2500C2

Ordering code: 02607194

Packaging Data

EAN1: 8719018026071

EAN3: 8719018026088

Packaging type: C2

Packed product information

Length: 9.15 cm

Width: 4.6 cm

Height: 7.65 cm

Pack Quantity: 2 pcs

MOQ (for professionals): 4 sets/8 pcs

Outer pack information

Length: 20.2 cm

Width: 10.5 cm

Height: 10 cm

