



Philips Philips
Water dispenser

Countertop

Reverse osmosis filtration
Ambient and hot
4.8L tap water tank

ADD6902HGNO1

Crisp-tasting water guaranteed, ambient & hot

This water dispenser is super suitable for young people and smaller households who chase for easy but exquisite life. Apart from its retro and delicate design, it also gives you crisp-tasting water guaranteed by SGS great taste test!

1

- Aquaporin Inside technology filters water better than before
- Water taste refined by the high-quality activated carbon
- Fresh hot water on demand within seconds

2

- 5 temperature settings for your different needs
- Commonly-used volume settings at the touch of a button
- Portable purified water jug
- Plug and play; no installation required
- Filter lifetime indicator reminds on-time filter replacement
- 2,000L filtration capacity
- Self-cleaning mode to clean water pipes regularly

PHILIPS

Specifications

Filtration performance

- Chlorine reduction
- Pesticides reduction
- Water hardness reduction
- Bacteria reduction
- VOC reduction
- Viruses reduction
- Heavy metals reduction
- Total dissolved solids (TDS) reduction
- Drain ratio: 75% (3:1)
- Stage of filtration: 5-stage

Applicable conditions

- Rated voltage: 220V
- Rated power: 2150W

Filter specifications

- Filtration capacity: 2000L
- Filter precision: down to 0.0001 microns

- 4in1 AQP RO filter: ADD541/90
- All-in-One AQP RO filter: Up to 12 months
- Post coconut shell activated carbon filter: ADD547/90

General specifications

- Applicable inlet water: RO purified water
- Product Dimension (LxWxH): 211*398*333 mm
- Inlet water temperature: 5-38? °C
- Display: LED
- Purified water jug
- Purified water jug capacity: 1.3L
- Tap water tank: 4L capacity
- Country of origin: Made in China
- Inlet water pressure: 0.1-0.4MPa

Country of origin

- Water dispenser: China

Highlights

Aquaporin Inside technology filters water

Harnessing the power of nature, the biomimetic reverse osmosis membrane incorporates aquaporin proteins to replicate nature's own water filtration process and filters water faster and better than ever before. The filtration system can effectively remove 110 kinds of harmful substances down to 0.0001 micron*, providing you and your family with clean and fresh-tasting water.

Water taste refined by the high-quality activated

The activated carbon filter is made of natural coconut shell, which has an iodine value as high as 1200 and refined pores down to 1 micron. Such high quality guarantees a crisp and pure taste. Examined and recognized by SGS water sommeliers!

Fresh hot water on demand within seconds

The fresh hot water comes out within seconds, at the exact temperature you like, bringing out the maximum aroma in your drinks.

5 temperature settings for your different needs

We provide pure-tasting water from ambient to piping hot. Tea, coffee, baby formula. You can do a million things with it.

Commonly-used volume settings

You can always find a suitable water volume to fill your cups, mugs, bottles, or even jugs.

Portable purified water jug

Thanks to the design of the portable purified water jug, you always have plenty of pure-tasting water to carry around for cooking and making drinks. You can even chill one jug with filtered water in the fridge for cold drinks, and keep the other jug placed in the water station for refilling.

Plug and play; no installation required

The dispenser will start to work as soon as you connect the power and turn it on. No need to plumb in.

Filter lifetime indicator reminds

The filter lifetime indicator reminds you to replace the filter on time, to ensure the best filtration performance.

2,000L filtration capacity

The RO filter is good for filtering 2,000 liters of water, helping to save thousands of plastic bottles every year. So its not only good for you, its good for the environment too.

Self-cleaning mode to clean water pipes regularly

After you return from holiday, simply activate the self-cleaning mode to rinse the water pipes with hot water, so that you feel more confident about the hygiene of the system.



Issue date 2024-02-03

Version: 1.1.1

EAN: 48 95244 61174 9

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

** Tested by 3rd party testing agency under laboratory conditions.
The contaminants or other substances reduced by this water filter
are not necessarily in all users' water.