# **TPV Philips Product Carbon Footprint (PCF) Information Sheet**

Company Name	TPV Technology Ltd.	
Manufacturer Name	MMD (Shanghai) Electronics Technology Co.,Ltd	TPV
Commercial Name	Curved Business Monitor– Philips	VISION INNOVATOR
Model Number	49B2U5900CH	
Review Date	2023-11-30	PHILIPS
Issue Date	2023-12-01	FILLIPS

Product Environmental Attributes						
	Expected Product Lifetime	3 years				
(a) Product Carbon Footprint Value:	(see Note 1 below)	5 years   901.77 kg of CO₂e				
	Estimates Uncertainty	± 8.97%				
(b) Product Picture:	(c) Life Cycle Detail by Life Stag	је (Pie Chart):				
	Expected Product Lifetime: 3 years    Use, 195.58,	Expected Product Lifetime: 5 years (kg CO2e/Pcs)  Use, 325.97, 36.15%.  End-of-life, 0.08, 0.01%  Raw materials  Manufacture Transport Use End-of-life  Raw materials  Andrecture Transport Use End-of-life				

## Note 1: Disclaimer:

All estimates of carbon footprint are uncertain.

This information sheet contains a description of the carbon footprint data for this declared product, which is based on estimates of the current state of the product life cycle, but is subject to known or unknown risks or uncertainties, so actual results may be different from the statement.

### Note 2:

This product is based on the ISO 14067:2018 standard for carbon footprint inventory and calculation. And this product use SimaPro 9.5.0.0 for PCF calculation tool. The lifecycle impact assessment methodology follows the IPCC 100-year Greenhouse Gas Emissions Assessment Method (IPCC 2021 GWP 100a) to calculate the CO2 emission equivalent of a product from raw material extraction to product disposal (Cradle to Grave).

## Note 3:

This calculation was based upon a Philips 49B2U5900CH with the assumptions and configuration described in the calculation assumptions in the next page.

#### Note 4:

This pie chart provides the percent contribution of the mean value for each element of the analysis for the full life cycle CO<sub>2</sub>e impacts of the product. If individual elements displaying 0% are less than 0.1%.

## **TPV Philips Product Carbon Footprint (PCF) Information Sheet**

Assumption Table					
Category	Element	Unit	Input		
Product Specifics	Product Weight (with packaging)	kg	19.38		
	Screen Size	inches	49		
	Product Lifetime	years	3		
	Standby Mode & Power-On Mode	W	0.3 & 45.1		
	Estimated standby hour & usage hour	hrs	8 & 8		
	Estimated total <u>annual</u> standby and power-on consumption	kwh	90.8		
Location	Assembly Location	no unit	CN		
	Use Location	no unit	GLO		
Transport from Assembly to Customer	To country of use: by air	no unit	N/A		
	To country of use: by ship	no unit	Applicable		
	To country of use: by rail	no unit	N/A		
	To country of use: by truck	no unit	Applicable		
	In country of use: by air	no unit	N/A		
	In country of use: by ship	no unit	N/A		
	In country of use: by rail	no unit	N/A		
	In country of use: by truck	no unit	Applicable		
End of Life	Waste incineration	%	5		
	Material recycling	%	95		

The PCF value is calculated using the specific attributes above for assembly, use and transportation mode.

#### Notes:

Life Cycle Analysis (LCA) can be grouped into five categories which include Raw Material, Manufacture, Transport, Use, and End-of-Life. Below is a brief description of each phase.

Raw Material: This life cycle phase captures emissions generated during the extraction, production, and transport of raw materials.

<u>Manufacture:</u> This life cycle phase captures emissions generated during the manufacture of subassemblies (including the product packaging) and product assembly.

<u>Transport:</u> Emissions included in the distribute phase include all those generated during the air, ocean or land distribute of finished or semi-finished Philips products between Philips facilities and from Philips facilities to customers.

<u>Use:</u> In use energy consumption is calculated in accordance with the U.S. Environmental Protection Agency's Energy Star® Typical Energy Consumption (TEC) methodology. Calculated energy consumption is then used in combination with average emissions factors for the designated country of use to calculate emissions. Estimated monitor usage days by end user are 250 days a year.

<u>End-of-life:</u> The recycle rate is calculated based on the company's own calculated WEEE recycle rate. It is also assumed that the balance of the product waste materials is disposed of by landfill. Emissions generated during the mechanical destruction, separation and transport of end of life materials are included in the calculation.