

Philips PerfectCare Pure  
Steam generator iron

Max 5 bar pump pressure

220 g steam boost  
PureSteam cartridge

GC7620/30



# Faster and easier ironing

with OptimalTEMP technology

Iron your garments without adjusting temperature thanks to the revolutionary OptimalTEMP technology. Most compact steam generator, easy to store & carry. 99% calc free, Pure Steam anti-scale cartridges increase life by 5 times

## **Fast and powerful ironing**

- Steam boost up to 180 g

## **Fast and powerful ironing**

- Max 5 bar pump pressure
- Our best gliding soleplate
- 1.5 L water tank, up to 2 hours of ironing
- Ready to use in 2 minutes with unlimited refill
- The most compact and lightest steam generator
- Anti-scale cartridge delivers pure steam

## **Carefree ironing, no temperature setting required**

- Iron from jeans to silk with no temperature setting required
- Safe to leave the hot soleplate on the ironing board

# PHILIPS

# Highlights

## 1.5 L water tank



Thanks to the 1.5 L watertank capacity, you can iron up to 2 hours continuously without any refills. The large filling hole makes the refilling fast. You can either fill your steam generator iron under the tap or use a jug / large bottle.

## Steam ready in 2 minutes



Steam is ready to use in 2min and can be refilled at anytime during ironing.

## Max 5 bar pump pressure



The more steam, the faster the ironing. Consistent powerful steam is generated which penetrates deep inside the garments making ironing faster and better. Steam power can be regulated to fit your needs.

## OptimalTEMP technology



"Now you can iron from jeans to silk with no temperature setting required. Guaranteed no burn on all ironable fabrics. Revolutionary technology with the 1) Advanced Smart Control Processor which controls precisely the soleplate temperature. You do not need to adjust temperature 2) Compact ProVelocity steam engine delivers more steam for ironing faster. It enables compact design of your steam generator for easier storage"

## Safe rest



The Philips innovative OptimalTEMP technology guarantees no burn on all ironable fabrics. During ironing, no need to put your iron back to the base station, just leave the hot iron soleplate directly on the garments or cotton ironing board cover without additional resting accessory. It will not damage any of your ironable garments, neither the board. This makes your ironing easier with less wrist efforts.

## Compact and light

The compact design makes your appliance easy to storage. Space will never be an issue again! As it is very light, your appliance is easy to

carry. Its light weight iron will make your ironing much more comfortable.

## PureSteam Anti-calc cartridge

The replaceable PureSteam Anti-scale cartridges are proven to be the most efficient system to filter scale on a steam generator, up to 99% of scale filtration, even with hard water. The appliance is guaranteed 5 years against scale related issues. The steam is clean and the product life is extended by 5 times. Intelligent, the system warns when the cartridge needs to be replaced. A cartridge lasts in average 3 months. To continue using your appliance, you can either use demineralized water while keeping the old cartridge inside, or replace it by a new cartridge. 2 cartridges are included

## Steam boost up to 180 g



The steam boost can be used for vertical steaming and tough creases.

## T-ionicGlide soleplate



Our best gliding and most scratch resistant, 5star rated soleplate with integrated Titanium-Oxide layer

# Specifications

## Calc management

- Calc clean reminder
- Suitable for tap water
- Calc clean solution: PureSteam Anti-scale cartridge

## Weight and dimensions

- Weight of iron: 1.2 kg
- Product dimensions (WxHxL): 35.4 x 19.3 x 22.4 cm
- Packaging dimensions (WxHxL): 40 x 23 x 28 cm
- Weight of iron + base: (with 1 cartridge) 3.19 kg

## Easy to use

- Refill any time
- Filling and emptying water: Extra large filling hole
- Heat up time: 2 minute(s)
- Safe for all fabrics: Even for delicates like silks
- Water tank capacity: 1500 ml

- Cord freedom (swivel): 180 degree cord freedom
- Cord storage: Cord clip
- Power cord length: 1.8 m
- Hose length: 1.6 m
- Hose storage: Hose storage compartment

## Sustainability

- User manual: 100% recycled paper

## Fast & powerful crease removal

- OptimalTEMP technology
- Continuous steam output: 120 g/min
- Soleplate: T-ionicGlide
- Power: 2400 W
- Pressure: Max 5 bar
- Steam boost: 220 g
- Vertical steaming
- Steam tip



Issue date 2024-02-13

Version: 1.1.1

EAN: 87 10103 76858 6

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)