



Philips Philips
On-Tap

X-Guard
Digital display screen

AWP3705P1

Crisp and pure-tasting water straight from the tap

Enjoy crisp and pure-tasting water whenever you turn on the tap, with the Philips X-Guard microfiltration system reducing up to 99% of chlorine and taste-impairing substances.

Build for your convenience

- Indicator tells the filter lifetime usage
- Easily switch among different modes
- Quick twist design for easy filter replacement
- One-click installation — no need for a plumber
- Effectively reduces chlorine and taste-impairing substances
- Delicious water at a fraction of the cost of bottled water

PHILIPS

Specifications

Filter specifications

- Filtration capacity: 1000 L
- Replacement filter cartridge: AWP305, AWP315

Input water conditions

- Input water temperature: 5-38°C °C

- Input water quality: Mains tap water
- Input water pressure: 0.15–0.35 Mpa Bar

General specifications

- Water flow rate: 2 L/min

Highlights

Indicator tells the filter lifetime usage

Digital filter lifetime display gives the user a reminder for on-time filter replacement

Easily switch among different modes

Filtered stream water is tailored for drinking and cooking, while unfiltered stream and unfiltered shower modes are suitable for washing dishes and other cleaning purposes.

Quick twist design for easy filter replacement

Effortlessly replace the expired filter with a new one with a simple twist.

One-click installation — no need for a plumber

After the correct adapter has been installed, simply attach the filter to the tap, release and you are good to go!

Effectively reduces chlorine and taste-impairing substances

With high-quality natural activated carbon, this X-Guard filter reduces up to 99% of chlorine and taste-impairing substances to give you crisp and pure-tasting water.

Delicious water at a fraction of the cost of bottled water

Great-tasting water at a fraction of the cost and waste of bottled water.



Issue date 2024-07-04

Version: 3.3.1

EAN: 48 95244 61113 8

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com