

Saeco Royal
Super-automatic
espresso machine

RI9914/01



Royal: No limits in espresso enjoyment

With Saeco Royal, you can prepare a high number of coffee specialties, thanks to the high capacity containers and to the exclusive Cappuccinatore

Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling

Always ready

- Milk specialties without the wait thanks to a double boiler

Bean- to-cup customization

- Adjust coffee length, intensity, temperature and strength

Easy to use

- Cup warmer
- Ergonomic in day-by-day operations

Easy to use

- Easy cleaning thanks to removable brewing group

 **Saeco**

Highlights

Professional double boiler



With 2 separate heating systems to cater for both the optimal coffee or milk frothing temperatures, this Saeco fully automatic espresso machine guarantees professional performance and speed everytime. You are able to prepare as many latte macchiatos and cappuccinos as you wish, one after the other and each just as good as the previous without waiting.

Coffe Customization



With Saeco you can always easily select the coffee length, intensity, temperature and strength you prefer. Your personal settings are memorized so you can enjoy your favourite coffee at the touch of a button.

Cup warmer



This feature allows you to not only store your espresso cups and glasses right on the espresso machine, it also pre-heats them letting the aroma unfold even better and guaranteeing a long-lasting crema

Ergonomy



Saeco is a synonym for convenience: refilling beans or water, emptying the coffee-dump box or the drip tray, all compartments are directly accessible.

Auto cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start on your machine and guides you with clear on-screen messages when you have to intervene. Descaling has never been so easy!

Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easily cleaning by rinsing under the tap ensuring maximum hygiene.

Specifications

Features

- Cappuccinatore

Perfect Espresso

- Espresso technology: Aroma-system: pre-brewing, Cup warmer

Technical data

- Voltage: 230 V
- Power: 2600 W
- Boiler: Stainless steel

- Pump Pressure: 15 bar

- Frequency: 50 Hz

Weight and dimensions

- Waste container capacity: 30 servings
- Coffee bean capacity: 300 g
- Water tank capacity: 2,4 L

Easy to use

- Usage: Instant steam (2 boilers)



Issue date 2024-02-13

Version: 1.1.1

EAN: 80 16712 01979 9

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com