



Philips
Pressurised steam
generator

GC8280

Great results, minimum effort

Endless, powerful steam with 1.4 liter water tank

Powerful yet surprisingly compact, this ironing system produces non-stop high steam with high pressure, making ironing fast and easy. Thanks to the 1.4 liter detachable water tank, you can iron for hours without interruption.

Fast and powerful ironing

- Up to 5 bar pressure
- Ready to use in 2 minutes with unlimited refill
- Continuous steam up to 140 g/min for fast crease removal

Reaches into tricky areas

- Steam tip lets you iron right into hard-to-reach areas

Full control

- LCD display to easily change settings

Smooth gliding

- SteamGlide soleplate for powerful steam and superb gliding

Iron up to 3 hours without refilling

- Xtra large detachable 1.4 liter water tank

PHILIPS

Highlights

Up to 5 bar pressure

5 bar

The more steam, the faster the ironing. Consistent powerful steam is generated which penetrates deep inside the garments making ironing faster and better. Steam power can be regulated to fit your needs.

Detachable water tank



To make ironing effortless you need a lot of steam. High steam output means a lot of refilling. The extra large 1.4 l water tank reduces the need of refilling.

Steam tip

The unique steam tip combines a particularly pointed front of the soleplate with special steam slots in the tip to reach right into the smallest and most difficult areas for the best ironing results.

Steam ready in 2 minutes



Steam is ready to use in 2min and can be refilled at anytime during ironing.

Continuous steam up to 140 g/m

Continuous steam output up to 140 g/min thanks to the small amounts of water that are pumped into the boiler each time. For perfect and fast crease removal.

LCD display

LCD display to easily change settings.

SteamGlide Soleplate



This specially designed soleplate combines superior ceramic coating for superior gliding on all fabrics and carefully designed vents for powerful crease removal.

Specifications

Technical specifications

- Frequency: 50-60
- Voltage: 220 - 240
- Boiler wattage: 1200
- Iron wattage: 800

Weight and dimensions

- Product weight: 6,06
- Product dimensions: 350 x 350 x 250

Easy to use

- Control: Temperature ready light, Variable steam settings
- Reaching tricky areas: Button groove, Steam tip
- Easy to set up and store: Easy cord and hose storage, Extra-large water inlet
- Water tank: Crystal clear

Smooth gliding

- Soleplate: SteamGlide soleplate

Comfortable ironing

- Cord length: 2,5 m
- Additional comfort: Iron lock, Steam trigger lock
- Anti-scale management: Easy Rinse
- Hose length: 1,9, 1.9 m
- No leakage: Drip-stop system
- Safe in use: Automatic shut-off when iron is left unattended, Overheat safety stop, Programmable safety shut-off
- Suitable for tap water

Crease removal

- Vertical Steam: Continuous vertical steam
- Soleplate: Optimal vent pattern



Issue date 2024-02-13

Version: 1.1.1

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com