



Philips
Professional Soundbar

2.1 Soundbar
with built-in subwoofer



HAL5023

Immersive TV Sound Experience

With built-in subwoofer

This sound enhancing subwoofer will extend the experience for guests using Philips MediaSuite TVs. Easy to install, set up and control, with a built-in subwoofer designed to add extra punch to special effects, music and more.

Professional and managed

- Easy set up and cloning via TV professional menu
- Smart power cable for quick installation
- Customizable sound configuration
- Controlled clearing of Bluetooth connections
- Control the soundbar with the TV remote control
- Freedom of placement - whether wall mounted or on a surface
- Anti-theft provision
- Professional warranty

A superior TV sound to match the content of choice

- More powerful TV sound
- Play your personal sound content via Bluetooth Audio

PHILIPS

Specifications

Convenience

- Wall mountable
- Anti-theft provision: cable

Sound

- Equalizer settings: Movie, Music, Voice, Stadium
- Speaker output power: 200W max / 100 W RMS (10% THD)
- Speaker configuration: 2.1 (2x 2" + 1x 3")

Connectivity

- Bluetooth: SBC, A2DP
- Bluetooth version: 4.2
- Number of HDMI connections: 1
- HDMI features: Audio Return Channel, Easylink (HDMI-CEC), HDMI 1.4

Power

- Power supply: 100-240VAC, 50/60Hz
- Power consumption: 30 W
- Standby power consumption: < 0.5 W

Accessories

- Included: Wall mount bracket (2pcs), Y-shaped power cord adapter, HDMI Cable, Warranty Leaflet

Dimensions

- Packaging dimensions (WxDxH): 91.5 x 18 x 13 cm

- Gross weight: 3.8 kg
- Product weight: 2.5 kg
- Gross Weight: 8.377 lb
- Packaging dimensions (WxDxH): 36.0 x 7.1 x 5.1 inch
- Product dimensions (WxDxH): 27.6 x 4.7 x 2.8 inch
- Product dimensions (WxDxH): 70 x 12 x 7 cm
- Product weight (lb): 5.512 lb

Packaging Data

- UPC: 8 71886 30043 6

Outer Packaging

- GTIN: 1 08 71886 30043 3
- Number of trade items: 4
- Outer carton (W x H x D): 94 x 29 x 38.5 cm
- Gross weight: 16.5 kg
- Outer carton (W x H x D): 37.0 x 11.4 x 15.2 inch
- Nett weight: 12 kg
- Tare weight: 4.5 kg
- Gross weight: 36.376 lb
- Nett weight: 26.455 lb
- Tare weight: 9.921 lb

Supported by

- MediaSuite 5000-series: HFL5114 HFL5214
- B-line 2000-series: BFL2114 BFL2214
- MediaSuite 6000-series: HFL6114 HFL6214

Highlights

Powerful TV sound

Hear more in everything you watch and every track you love. 2.1 channels bring out the best in effects, score and dialogue. The built-in subwoofer lets you feel the bass, whether you're listening to music or watching an action movie.

Bluetooth audio

Link your mobile device via Bluetooth and play your favourite sound tracks with the enhanced sound performance of the soundbar.

Easy set up and cloning

Easily configure the soundbar settings through the professional setup menu on the MediaSuite TV. All related settings can be copied and transferred to other TVs through cloning.

Smart power cable

With the specially designed power cable adapter, only one power socket is needed to power both the Soundbar and the TV.

Customizable sound config

Choose the best sound settings for the best sound experience. Being in control over the professional settings, you can set a.o. the default level and maximum volume limit. The chosen default configuration will be reset upon for each new user.

Controlled clearing

Linked to the user data clearance of the TV, it will be ensured that the Bluetooth pairing information from the used mobile devices will also be cleared.

TV remote control

No dedicated remote control required. Conveniently control the soundbar volume with the TV remote control.

Freedom of placement

Conveniently placed on a surface or mounted with the included wall brackets, the sleek trapezoid design looks great in any setting.

Anti-theft

Discourage unauthorised removal of the device with the anti-theft cable included.

Professional warranty

A professional device warrants a professional warranty: 3 years.



Issue date 2024-03-20

Version: 2.2.1

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Supporting TV models may require a software update.