

Philips
Professional LCD TV

32"
LCD
HD Ready

32HF7875



The ultimate interactive Hospitality TV

Philips LCD TV and SmartCard Slot

This stylish, energy efficient Hospitality TV with integrated SmartCard slot is our best tamper proof interactive solution. Your guests enjoy a great viewing experience optionally enhanced with bathroom music and a tailored welcome message.

Best total cost of ownership

- Wireless SmartLoader for fast cloning
- Installation menu locking
- External loudspeaker connector and extra power supply

Sustainable and safe

- SmartPower for energy saving
- Eco-friendly design and flame-retardant housing

Integrated system solution and future proof

- Tamper proof SmartCard slot
- Remote software upgrading

Great viewing experience and guest comfort

- Welcome message on screen display
- Integrated clock display with wake-up and message alarm
- Swivel stand with anti-theft provision
- Pixel Plus HD for better details, depth and clarity

PHILIPS

Highlights

Remote software upgrading

The TV software that controls hotel-specific features can be upgraded remotely through a certified system provider.

Integrated SmartCard Slot

The integrated SmartCard slot allows third parties to add new functionality to the TV through application cards, without the need for additional boxes and external connections. The TV can also be connected to external decoders and set-top boxes of all major interactive system providers, through the SerialXpress Control Interface (supporting UART and RS232 protocols) and the SmartPlug Control interface.

Wireless SmartLoader

Provides the ability to copy all programming settings from one TV set to other TV sets easily and wirelessly in less than a minute. The feature ensures uniformity between TV sets and significantly reduces installation time and costs.

External loudsp and power supply

The TV is equipped with an amplified audio connector for easy installation of external speakers (like for bathrooms), eliminating the need for investments in external equipment. The extra integrated power supply avoids the need for a separate power supply for an interactive system. In case of stand-alone use, the additional power supply can be switched off to save energy.

Installation menu locking

Prevents unauthorised access to installation and configuration settings, to ensure maximum guest convenience and avoid unnecessary reprogramming costs.

Pixel Plus HD



Pixel Plus HD is a picture processing technology that enables viewers to watch content that is vivid, natural and real. The results are superbly life-like pictures with incredible details and depth from any HD source.

Integrated clock display

The built-in clock display, which is also a wake-up alarm, eliminates the need for investment in an additional clock with cables and connections in the room. Automatic time synchronisation via teletext and preservation of alarm settings during short power outages further enhances guest comfort

Welcome message

A welcome greeting is displayed each time the TV set is switched on.

Swivel stand

This LCD TV comes with a swivel stand that allows your guests to adjust the TV so that they can watch TV from any position in the room. The stand can be secured to a table or furniture to provide additional security against theft.

SmartPower



The backlight intensity can be controlled and pre-set by the system to reduce the power consumption by up to 50%, which saves substantially on energy costs.

Eco-friendly design

Sustainability is integral to the way Philips does business. Philips TVs are designed and produced according to our EcoDesign principles aimed at minimising overall environmental impact, through lower power consumption, removal of hazardous substances, lower weight, more efficient packaging and better recyclability. Philips TVs also have a special housing of flame-retardant material. Independent tests carried out by emergency fire services have shown that whereas TVs can sometimes intensify fires caused by external sources, Philips TVs will not contribute to a fire.

Specifications

Picture/Display

- Aspect ratio: 16:9, Widescreen
- Diagonal screen size (inch): 32 inch
- Diagonal screen size (metric): 81 cm
- Panel resolution: 1366 x 768p
- Brightness: 500 cd/m²
- Picture enhancement: 3D Combfilter, 3/2 - 2/2 motion pull down, Active Control, Contrast Plus, Dynamic contrast enhancement, Digital Noise Reduction, Jagged Line Suppression, Progressive scan, Colour Transient Improvement, Luminance Transient Improver, Pixel Plus HD
- Contrast ratio (typical): 1500:1
- Display screen type: LCD WXGA Active Matrix TFT
- Dynamic screen contrast: 7500:1
- Response time (typical): 8 ms
- Viewing angle (horizontal): 178 degree
- Viewing angle (vertical): 178 degree
- Screen enhancement: Anti-Reflection coated screen

Supported Display Resolution

- Computer formats: 640 x 480, 60, 72, 75 Hz, 800 x 600, 60, 72, 75 Hz, 1024 x 768, 60, 70, 75 Hz, 1280 x 768, 60 Hz, 1366 x 768, 60 Hz
- Video Formats: 640 x 480i - 1Fh, 640 x 480p - 2Fh, 720 x 576i - 1Fh, 720 x 576p - 2Fh, 1280 x 720p - 3Fh, 1920 x 1080i - 2Fh

Tuner/Reception/Transmission

- Aerial Input: 75 ohm coaxial (IEC75)
- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: PAL I, PAL B/G, PAL D/K, SECAM B/G, SECAM D/K, SECAM L/L'
- Number of Pre-set Channels: 125
- Video Playback: NTSC, PAL, SECAM
- Tuner Display: PLL

Convenience

- Ease of Installation: Advanced Hotel Mode, Fine Tuning, Programme Name, Wireless Smart Loading, Keyboard lock-out, Security menu access
- Ease of Use: Auto Volume Leveller (AVL), Smart Picture, Smart Sound
- Clock: Sleep Timer, Wake-up Clock, Integrated LCD Clock Display
- Clock Enhancements: Synchro Time via PDC/TXT
- Comfort: Hotel Guest features, Switch on channel, Volume limitation, Welcome message, Message indicator
- Screen Format Adjustments: 4:3, 7 Widescreen Modes
- Teletext: 1000-page Hypertext
- Other convenience: Kensington lock, Convertible to consumer TV
- Firmware upgradeable: Remote upgrade hotel TV softw, Local upgrade total TV softw.
- Teletext languages: Cyrillic, Eastern European, Western European

Sound

- Output power (RMS): 2 x 10 W
- Sound System: Nicam Stereo, Stereo
- Sound Enhancement: Auto Volume Leveller, Incredible Surround

Loudspeakers

- Built-in speakers: 2

Connectivity

- Connectivity Enhancements: RJ12 connector, RJ45 connector, External Loudspeaker connector, HM-Link, Extra Power supply 12 V/1 W, SmartCard Xpress box ready, Fast Infrared loop through, Serial Xpress interface, SmartPlug Xpress Interface, Power on scart, SmartCard Expansion Slot
- Number of Scarts: 2
- Ext 1 Scart: Audio L/R, CVBS in/out, RGB
- Ext 2 Scart: Audio L/R, CVBS in/out, S-video in
- Other connections: Antenna IEC75, Headphone out, PC-In VGA
- Ext 3: Audio L/R in, CVBS in, S-video in
- Ext 4: Audio L/R in, YPbPr
- Ext 5: HDMI
- Ext 6: HDMI

Power

- Mains power: 100 - 240 V, 50/60 Hz
- Ambient temperature: 5°C to 40°C
- Power consumption: 150 W
- SmartPower high mode: 70 W
- SmartPower low mode: 118 W
- Active stand-by consumption: 19 W
- Passive stand-by consumption: 2 W
- SmartPower medium mode: 90 W

Green Specifications

- Safety: Flame-retardant housing

Accessories

- Included accessories: Warranty Leaflet, Power cord, Swivel stand with anti-theft
- Optional accessories: Wireless SmartLoader 22AV1135, Set up Remote RC2573GR, RC2886 (remote control)

Dimensions

- Set Width: 805 mm
- Set Height: 546 mm
- Set Depth: 112 mm
- Product weight: 14.91 kg
- Set width (with stand): 805 mm
- Set height (with stand): 610 mm
- Set depth (with stand): 210 mm
- Product weight (+stand): 17.78 kg
- Box width: 877 mm
- Box height: 641 mm
- Box depth: 267 mm
- Weight incl. Packaging: 21 kg
- Wall-mount compatible: 200 x 100 mm



Issue date 2024-03-24

Version: 5.0.5

EAN: 87 12581 32864 1

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com