

Philips
Professional LED LCD TV

32" Signature
LED
DVB-T/C MPEG 2/4

32HFL7382A



Be part of the action!

with Ambilight in an ultra-thin design

Like a painting on your wall, experience the latest in ultra-thin TV from Philips. Combining powerful LED picture performance and the immersion of Ambilight, be assured your guests are always part of the action.

Sustainable and safe

- Low power consumption
- Eco-friendly design and flame-retardant housing

Differentiating guest experience

- Volume limitation
- One combined channel list for Analogue and Digital channels
- 100 Hz Clear LCD, 2 ms performance for superb motion sharpness
- Ambilight Spectra 2 widens the viewing experience

Advanced hotel features and future proof

- Brilliant LED images with low power consumption
- Welcome message on screen display
- Programmable Switch On Channel
- Integrated Connectivity Panel
- Advanced EPG and channel list
- Installation menu locking

PHILIPS

Highlights

LED



The most advanced LED lighting technology in this TV combines an eye-catching minimalistic design with stunning image quality as well as the lowest power consumption in its category. On top of that, LED lighting technology does not contain any hazardous materials. Thus, with LED backlight you can enjoy low power consumption, high brightness, incredible contrast, sharpness and vibrant colours.

Ambilight Spectra 2



Add a new dimension to your viewing experience with Ambilight Spectra 2. This patented Philips technology enlarges the screen by projecting a glow of light, on two sides of the TV, from the back of the screen onto the surrounding wall. Ambilight automatically adjusts the colour and brightness of the light to match the picture, creating an immersive viewing experience. With Ambilight Spectra 2 movies truly come to life!

100 Hz Clear LCD (2 ms)



100 Hz Clear LCD creates extreme motion sharpness. The Double Frame Rate Insertion increases the sharpness of motion reproduction to more than twice that of conventional LCD, resulting in a performance with a response time of 2 milliseconds. Now you can enjoy clear images even with fast on-screen motion.

Integrated Connectivity Panel

The Integrated Connectivity Panel allows your guests to seamlessly connect their personal devices to your TV without the need for an external Connectivity Panel.

Low power consumption

Philips TVs are designed to minimise power consumption. This will not only reduce environmental impact but also lower operating costs.

Welcome message

A welcome greeting is displayed each time the TV set is switched on.

Volume limitation

This feature predefines the volume range within which the TV set is allowed to operate, preventing excessive volume adjustments and disturbance of neighbouring guests.

Installation menu locking

Prevents unauthorised access to installation and configuration settings, to ensure maximum guest convenience and avoid unnecessary reprogramming costs.

Eco-friendly design

Sustainability is integral to the way Philips does business. Philips TVs are designed and produced according to our EcoDesign principles aimed at minimising overall environmental impact, through lower power consumption, removal of hazardous substances, lower weight, more efficient packaging and better recyclability. Philips TVs also have a special housing of flame-retardant material. Independent tests carried out by emergency fire services have shown that whereas TVs can sometimes intensify fires caused by external sources, Philips TVs will not contribute to a fire.

Programmable Switch On Channel

Perfect for in-house advertising or information channels as it allows a predefined channel to be shown when the TV is turned on.

Advanced EPG and channel list

The attractive EPG and channel list include intuitive buttons with clear guiding graphics to easily locate your favourite channels.

One combined channel list

One integrated channel list for digital and analogue channels. This allows the guest to flick seamlessly between Analogue and Digital channels.

Specifications

Ambilight

- Ambilight light system: LED-wide colour
- Dimming Function: Manual and via Light Sensor

Picture/Display

- Aspect ratio: Widescreen
- Diagonal screen size (inch): 32 inch
- Diagonal screen size (metric): 81 cm
- Colour cabinet: Silver-brushed deco-front with black cabinet
- Panel resolution: 1920 x 1080p
- Brightness: 450 cd/m²
- Picture enhancement: Active Control + Light sensor, Digital Noise Reduction, Luminance Transient Improver, Dynamic contrast enhancement, 100 Hz Clear LCD, HD Natural Motion
- Dynamic screen contrast: 500,000:1
- Response time (typical): 2 ms
- Viewing angle: 176° (H)/176° (V)
- Peak Luminance ratio: 65 %
- Screen enhancement: Anti-Reflection coated screen
- Colour processing: 4 trillion colours (14-bit RGB)

Tuner/Reception/Transmission

- Aerial Input: 75 ohm coaxial (IEC75)
- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: PAL I, PAL B/G, PAL D/K, SECAM B/G, SECAM D/K, SECAM L/L', DVB COFDM 2K/8K
- Digital TV: DVB Terrestrial*, DVB-C MPEG4*, DVB-T MPEG4*
- Video Playback: PAL, SECAM, NTSC

Convenience

- Child Protection: Child Lock+Parental Control
- Ease of Installation: Programme Name, Auto Programme Naming, Sorting
- Ease of Use: Smart Picture, Smart Sound
- Clock: Sleep Timer
- Comfort: Hotel Guest features, Welcome message, Volume limitation
- Screen Format Adjustments: Movie expand 16:9, Widescreen, Super Zoom, unscaled (1080p dot by dot), Auto Format
- Multimedia: USB autobreak-in
- Electronic Programme Guide: 8-day Electronic Programme Guide, Now + Next EPG

- Teletext: 1200-page Hypertext
- Firmware upgradeable: Firmware auto upgrade wizard, Firmware upgradeable via USB

Sound

- Output power (RMS): 20 W (2 x 5 W + 10 W)
- Sound System: Mono, Stereo, Nicam Stereo
- Sound Enhancement: Auto Volume Leveller, Dynamic Bass Enhancement, Incredible Surround, Treble and Bass Control

Connectivity

- Audio Output - Digital: Coaxial (cinch)
- EasyLink (HDMI-CEC): One touch play, System standby, Remote control pass-through, System audio control
- Front/Side connections: USB
- Ext 1 Scart: Audio L/R, RGB
- HDMI 1: HDMI v1.3
- Ext 2 Scart: Audio L/R, RGB
- HDMI 2: HDMI v1.3
- Other connections: Headphone out, PC Audio in
- HDMI 3: HDMI v1.3
- Ext 3: Audio L/R in, YPbPr

Power

- Mains power: 220 - 240 V, 50/60 Hz
- Ambient temperature: 5°C to 40°C
- Standby power consumption: 0.15 W
- Power consumption (typical): 71 W
- Off mode power consumption: 0.01
- Annual energy consumption: 103.66 kWh
- Presence of lead: Yes*

Accessories

- Included accessories: Remote Control, Tabletop swivel stand, Quick start guide, Warranty Leaflet
- Optional accessories: Set up remote 22AV8573/00

Dimensions

- Set Width: 777 mm
- Set Height: 472 mm
- Set Depth: 42 mm
- Product weight: 9.5 kg
- Set width (with stand): 777 mm
- Set height (with stand): 540 mm
- Set depth (with stand): 221 mm
- Product weight (+stand): 11.6 kg
- Box width: 950 mm

Rear connectors



Side



Rear bottom connectors



Issue date 2024-03-24

Version: 3.0.2

EAN: 87 12581 55802 4

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Typical on-mode power consumption measured according to IEC62087 Ed 2.

* Annual energy consumption is calculated using the typical power consumption of 4 hours per day, 365 days per year.

* This television contains lead only in certain parts or components where no technology alternatives exist in accordance with existing exemption clauses under the RoHS Directive.