

Philips  
professional flat TV

15"  
LCD

15HF8442



## System Prepared Flat TV

Specially designed for in-room entertainment

An elegantly designed TV that delivers best-in-class performance for your in-room entertainment setup. Optional SmartCard XPress box available to enable easy integration of third-party interactive services.

### **Advanced hotel features and future proof**

- Switch On Channel Programming
- Security Menu Access
- Front Controls Locking
- Volume limitation
- Welcome message on screen display
- Built-in FM radio
- Wireless SmartLoader for fast cloning

### **Vivid, natural and razor sharp images**

- High-definition LCD XGA display, 1024 x 768p
- Crystal Clear III for natural images with enhanced quality
- 2D Combfilter sharpens images for finer detail

### **Interactive System Prepared, Future-Proof**

- Optional extra Power Supply (12V)
- Serial Xpress™ Control interface

# PHILIPS

# Highlights

## Wireless SmartLoader

Provides the ability to copy all programming settings from one TV set to other TV sets easily and wirelessly in less than a minute. The feature ensures uniformity between TV sets and significantly reduces installation time and costs.

## Welcome message

A welcome greeting is displayed each time the TV set is switched on.

## Volume limitation

This feature predefines the volume range within which the TV set is allowed to operate, preventing excessive volume adjustments and disturbance of neighbouring guests.

## Front Controls Locking

Prevents unauthorised access to TV functions

## Switch On Channel Programming

Perfect for in-house advertising or information channels as it allows a predefined channel to be shown when the TV is turned on.

## Security Menu Access

Provides conditional access to installation and configuration settings via a special code or master remote control

## Built-in FM radio

The integrated FM radio offers guests additional comfort without the extra investment in radio receivers.

## SmartCard Xpress Box

The optional SmartCard Xpress Box can be mounted at the back of the TV set and allows third-party decoders and application cards to interface with the TV, adding new functionality to the TV. The TV can also be connected to external decoders and set-top boxes of all major interactive system providers through the Serial Xpress Control Interface (supporting UART and RS232 protocols) and the SmartPlug Control interface.

## Serial Xpress™ Control

The Serial Xpress™ Control interface is compatible with all major premium entertainment services. The protocols enable the TV to be connected with external decoders, set-top boxes and PC based solutions. Supports UART and RS232 protocols.

## Optional extra Power Supply

The (optional) Extra Power Supply ensures operation of the Expansion Slot, the Clock Display and Wake-up Alarm when the TV set is switched off.

## Upgradable software

The upgradable software architecture ensures that the TV is future proof and compatible with new technologies and developments, securing your investment.

## Crystal Clear III

Crystal Clear III combines a whole range of enhancements to provide a better picture. They include a 2D Comb filter, Dynamic contrast, Blue stretch and Green enhancement so that you always get the most natural looking colours.

## LCD XGA display, 1024 x 768p

This XGA display with state-of-the-art LCD screen technology has a widescreen HD resolution of 1024 x 768p pixels. It produces brilliant flicker-free progressive scan pictures with optimum brightness and superb colours. This vibrant and sharp image will provide you with an enhanced viewing experience.

## 2D Combfilter

The 2D combfilter separates chrominance (colour) from luminance (brightness) information in the video signal for independent processing to improve picture resolution and minimise distortion.

# Specifications

## Picture/Display

- Aspect ratio: 4:3
- Diagonal screen size (inch): 15 inch
- Diagonal screen size (metric): 39 cm
- Panel resolution: 1024 x 768p
- Brightness: 450 cd/m<sup>2</sup>
- Picture enhancement: Progressive scan, Sharpness Adjustment, 2D Combfilter, Active Control, Digital Noise Reduction, Crystal Clear III, Colour Transient Improvement
- Contrast ratio (typical): 400:1
- Display screen type: LCD XGA Active Matrix TFT
- Response time (typical): 16 ms
- Viewing angle (horizontal): 130 degree
- Viewing angle (vertical): 100 degree
- Screen enhancement: Anti-Reflection coated screen

## Supported Display Resolution

- Computer formats: 640 x 480, 60, 72, 75, 85 Hz, 800 x 600, 56, 60, 72, 75, 85 Hz, 1024 x 768, 60 Hz

## Tuner/Reception/Transmission

- Aerial Input: 75 ohm coaxial (IEC75)
- Tuner bands: Hyperband, S-Channel, UHF, VHF, FM
- TV system: PAL B/G, PAL D/K, PAL I, SECAM B/G, SECAM D/K, SECAM L/L'
- Number of Pre-set Channels: 127
- Video Playback: NTSC, PAL, SECAM
- Tuner Display: PLL

## Convenience

- Ease of Installation: Fine Tuning, PLL Digital Tuning, Programme Name
- Ease of Use: Auto Volume Leveller (AVL), Smart Picture, Smart Sound, FM Radio, On-Screen Display
- Clock: Sleep Timer
- Remote Control: TV
- Remote control type: RC2886

- Teletext: 10-page Smart Text
- VESA Mount: 100 x 100 mm
- Teletext enhancements: 4 favourite pages

## Sound

- Output power (RMS): 2 x 2 W
- Sound System: Nicam Stereo
- Sound Enhancement: Smart Sound
- Music Power: 8 W

## Loudspeakers

- Built-in speakers: 2

## Connectivity

- Connectivity Enhancements: RJ12 connector, RJ45 connector
- Front/Side connections: Audio in, Headphones Out, S-video in, CVBS in
- Ext 1 Scart: Audio L/R, CVBS in/out, RGB
- Other connections: Antenna IEC75, FM Antenna, PC-In VGA

## Power

- Mains power: AC 90 V–240 V 50/60 Hz
- Ambient temperature: 5°C to 40°C
- Power consumption: 32 W W
- Standby power consumption: < 3 W

## Accessories

- Included accessories: Tabletop stand, Remote Control, Power cord, User Manual

## Dimensions

- Product weight: 5.8 kg
- Weight incl. Packaging: 7.5 kg
- Bezel colour: Silver Frost
- Product dimensions (WxDxH): 467 x 308 x 80
- Outer carton dimensions WxDxH: 543 x 480 x 198
- Height (with base): 357 mm
- Depth (with base): 178 mm



Issue date 2024-04-02

Version: 8.0.11

EAN: 87 10895 82859 8

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)