



Philips  
professional flat TV

15"  
LCD

15HF5234



## Hospitality Flat TV

with Wireless Cloning for fast installation

Compact, slim and stylish. This 15 inch LCD hospitality TV offers everything you need to make guests feel at home, while saving time and keeping cost of ownership down for the hotelier.

### **Best total cost of ownership**

- Wireless SmartLoader for fast cloning
- Installation menu locking
- Consumer TV Convertible
- Front/Side controls locking
- Built-in FM radio

### **Maximum guest comfort**

- Volume limitation
- Switch On Channel Programming

### **Great viewing experience and guest comfort**

- Crystal Clear III for natural images with enhanced quality
- 2D Combfilter sharpens images for finer detail
- Virtual Dolby Surround for a cinema-like audio experience

# PHILIPS

# Highlights

## **Wireless SmartLoader**

Provides the ability to copy all programming settings from one TV set to other TV sets easily and wirelessly in less than a minute. The feature ensures uniformity between TV sets and significantly reduces installation time and costs.

## **Front/Side controls locking**

Selecting the option in the setup menu to lock or unlock access to the front and side controls of the TV prevents unauthorised access to the TV menu, saving the hotelier the time and effort of re-installing.

## **Built-in FM radio**

The integrated FM radio offers guests additional comfort without the extra investment in radio receivers.

## **Consumer TV Convertible**

Easily converts the TV from Commercial operation to Consumer settings for after-market sales.

## **Installation menu locking**

Prevents unauthorised access to installation and configuration settings, to ensure maximum guest convenience and avoid unnecessary reprogramming costs.

## **Volume limitation**

This feature predefines the volume range within which the TV set is allowed to operate, preventing excessive volume adjustments and disturbance of neighbouring guests.

## **Switch On Channel Programming**

Perfect for in-house advertising or information channels as it allows a predefined channel to be shown when the TV is turned on.

## **Crystal Clear III**

Crystal Clear III combines a whole range of enhancements to provide a better picture. They include a 2D Comb filter, Dynamic contrast, Blue stretch and Green enhancement so that you always get the most natural looking colours.

## **2D Combfilter**

The 2D combfilter separates chrominance (colour) from luminance (brightness) information in the video signal for independent processing to improve picture resolution and minimise distortion.

## **Virtual Dolby Surround**

Virtual Dolby Surround is a processing technology for enhancing surround sound effects. It will create the sensation of Dolby Pro Logic without the necessity of additional rear speakers. You become totally immersed in your television experience.

# Specifications

## Picture/Display

- Aspect ratio: 4:3
- Diagonal screen size (inch): 15 inch
- Diagonal screen size (metric): 38 cm
- Panel resolution: 1024 x 768p
- Brightness: 450 cd/m<sup>2</sup>
- Picture enhancement: 2D Combfilter, Active Control, Colour Enhancement, Crystal Clear III, Progressive scan, Sharpness Adjustment
- Contrast ratio (typical): 500:1
- Display screen type: LCD XGA Active Matrix TFT
- Response time (typical): 16 ms
- Viewing angle (horizontal): 140 degree
- Viewing angle (vertical): 125 degree
- Screen enhancement: Anti-Reflection coated screen

## Supported Display Resolution

- Computer formats: 640 x 480, 60, 67, 72, 75 Hz, 800 x 600, 56, 60, 72, 75 Hz, 1024 x 768, 60, 70, 75 Hz, 720 x 400, 70 Hz, 832 x 624, 75 Hz, 1280 x 768, 60 Hz
- Video Formats: 640 x 480p - 2Fh, 720 x 576p - 2Fh, 1280 x 720p - 3Fh, 1920 x 1080i - 2Fh

## Tuner/Reception/Transmission

- Aerial Input: 75 ohm coaxial (IEC75)
- Tuner bands: Hyperband, S-Channel, UHF, VHF, FM
- TV system: PAL, PAL I, PAL B/G, PAL D/K, SECAM, SECAM B/G, SECAM D/K, SECAM L/L'
- Number of Pre-set Channels: 99
- Video Playback: NTSC, PAL, SECAM
- Tuner Display: PLL

## Convenience

- Ease of Installation: Automatic Channel Install (ACI), Autostore, Fine Tuning, PLL Digital Tuning, Programme Name, Wireless Smart Loading
- Ease of Use: FM Radio, Side Control, Smart Picture, Smart Sound
- Comfort: Hotel Guest features, Sleep timer
- Screen Format Adjustments: 16:9 compress, 4:3, 4:3 expand
- Remote Control: TV
- Remote control type: RCFE05SMU00
- OSD Languages: English, French, German, Italian,

Spanish

- Teletext: 10-page Smart Text
- Other convenience: Kensington lock
- VESA Mount: 100 x 100 mm
- Teletext enhancements: 4 favourite pages, Fast text

## Sound

- Output power (RMS): 2 x 2 W
- Sound System: Nicam Stereo, Virtual Dolby Surround
- Sound Enhancement: Auto Volume Leveller

## Loudspeakers

- Built-in speakers: 2

## Connectivity

- Number of Scarts: 1
- Front/Side connections: Audio L/R in, CVBS in, Headphones Out, S-video in
- Ext 1 Scart: Audio L/R, CVBS in/out, RGB
- Other connections: Antenna IEC75, DVI-I, PC Audio in

## Power

- Mains power: 110 - 240 V, 50/60 Hz
- Ambient temperature: 5°C to 40°C
- Power consumption: 42W Normal operation W

## Accessories

- Included accessories: Power cord, Remote Control, Tabletop stand, User Manual
- Optional accessories: Wireless SmartLoader 22AV1120

## Dimensions

- Set Width: 375 mm
- Set Height: 337 mm
- Set Depth: 62 mm
- Product weight: 4 kg
- Box width: 454 mm
- Box height: 391 mm
- Box depth: 215 mm
- Weight incl. Packaging: 5.8 kg
- Width (with base): 375 mm
- Height (with base): 375 mm
- Depth (with base): 169 mm



Issue date 2024-03-24

Version: 5.0.6

EAN: 87 10895 97468 4

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)