

Philips
LCD monitor

48 cm (19")
multimedia
SXGA

190G6FB



Surround yourself in entertainment

Place yourself in the center of a totally awesome entertainment experience with the Philips 190G6. Exciting concave design surrounds you with sights, sounds and sensations that bring movies, music and games to life like never before.

Maximum comfort for computainment

- High-speed USB 2.0 hub for easy connections
- Preset hot keys to optimize sound for favorite music genres
- Displays video signals from a variety of AV sources

Outstanding front of screen performance

- Ready to display HD content
- Fast 8ms On/off response time: Great text & graphics display
- ActiveBright for high brightness and razor sharp colors

Radically cool design

- Concave design surrounds you with awesome entertainment

Superior sound

- Digitally transmitted PC audio
- Easy-to-use Sound Agent 2 optimizes the audio experience
- 20-watt active subwoofer for deeper bass experience
- 3D virtual surround sound

PHILIPS

Highlights

ActiveBright

The ActiveBright delivers high-definition-TV-like quality by displaying brilliant, razor sharp colors and a wide viewing angle for the very best in multimedia entertainment.

High definition monitor

A high definition monitor is a display device designed to deliver the exceptional picture quality of high definition pictures, one fully prepared for HD sources like HD set top boxes. A HD monitor offers picture quality beyond that of progressive scan, conforming to strict standards for HD screens that display high resolution, top picture quality signals through a universal connection for either analog VGA or uncompressed DVI digital connections and supports HDCP. It displays 720p (1280x720p @ 50 and 60 Hz progressive) and 1080i (1920x1080i @ 50 and 60 Hz interlaced) signals.

8ms response time (On/Off)

On-Off response time is the period required for a liquid crystal cell to go from active (black) to inactive (white) and back to active (black) again. It is measured in milliseconds. Faster is better: Lower response time means faster transitions and, therefore, results in fewer visible image artifacts in the display of transition of text and graphics. On-Off response time is a more important measure in the display of business content like documents, graphs and photos.

20-watt active subwoofer

A subwoofer is a speaker that reproduces the lower end of the audio spectrum. The monitor has a separate subwoofer that is optimized to reproduce bass frequencies and satellite speakers that are optimized for mid- and high-range frequencies. The result is a system that powerfully reproduces the full range of audio frequencies from deep bass to crystal clear high notes with the minimum of distortion.

3D surround sound

Virtual 3D Surround Sound is an advanced sound enhancement technology that provides a simulated surround sound effect from stereo sources for a more immersive and realistic soundscape.

Sound Agent 2

Sound Agent 2 is intelligent software that comes with a fun and easy-to-use graphical interface. It takes the confusion out of PC audio by automatically optimizing sounds for all popular formats. Sound Agent 2 makes it easy to fine-tune any audio performance to suit your personal musical taste.

USB Digital Audio

Digital transmission of PC audio signals over a USB cable instead of the old analog mini-jack cable that delivers instant up mix for incredible surround effects without the distortion caused by digital/analog conversion.

High-speed USB 2.0 hub

The universal serial bus or USB is a standard protocol for linking PCs and peripherals. Because it delivers high speed at a low cost, USB has become the most popular method for connecting peripheral devices to a computer. A USB 2.0 hub located on the monitor provides a conveniently located, easy-to-use, high-speed connection for reading, writing, loading and transferring programs, data, digital media or music files to, from or among your PC and one or more USB devices.

AV device

Display signals from a rich variety of AV devices.

Preset hotkeys

Preset hotkeys that instantly change audio settings for enhanced surround sound effects. Four audio environments are offered: Neutral, Rock, Jazz and Classic. There's a mode just right for every application.

Exciting concave design

Cutting edge concave design is a breakthrough in entertainment that surrounds you with exciting sights and sounds, putting you right smack in the center of a totally encompassing, totally awesome entertainment experience.



Specifications

Connectivity

- Audio output: Subwoofer Out
- PC: 3.5 mm PC audio input x1, DVI-D x1, D-Sub x1
- USB: Up stream port x 1, Down stream port x 2
- AV input: Audio (L/R) for CVBS & S-Video, Audio (L/R) for YPbPr x1, Component (YPbPr) x1, Composite (CVBS) x1, SCART x1, S-video x1
- Sync Input: Composite Sync, Separate Sync
- Audio input for data: Digital Audio (via USB) 1x
- Headphone: 3.5 mm
- Microphone: Microphone in 3.5 mm jack

Picture/Display

- Panel Size: 19"/ 48 cm
- LCD panel type: 1280 x 1024 pixels, High gloss, RGB vertical stripe
- Pixel pitch: 0.098 (H) x 0.294 (V) mm
- Optimum resolution: 1280 x 1024 @ 60Hz
- Brightness (nits): 420 nit
- Display colors: 16.2 M
- Contrast ratio (typical): 700:1
- Response time (typical): 8 ms
- Viewing angle: 160° (H) / 160° (V), @ C/R > 10
- Horizontal Scanning Frequency: 30 - 82 kHz
- Vertical Scanning Frequency: 56 - 76 Hz
- Maximum Resolution: 1280 x 1024 @ 75Hz
- Effective viewing area: 376.3 x 301.1 mm
- sRGB
- Video Dot Rate: 135 MHz

Convenience

- Plug & Play Compatibility: DDC/CI, sRGB, Windows 98/ME/2000/XP
- User convenience: On-screen Display
- Monitor Controls: Auto, Brightness Control, Input select, Left/Right, Menu (OK), Power On/Off, Up/Down, Volume control
- Regulatory approvals: CB, CCC, CE Mark, FCC-B, UL, CSA, GOST, MPRII, NUTEK, Energy Star, SEMKO
- OSD Languages: English, French, German, Italian, Simplified Chinese, Spanish
- Other convenience: Kensington lock compatible
- Tilt: -5° to 25°
- Ease of Use: Hot Keys

Sound

- Output Power: 5 W RMS x 2 Stereo + 20 W x 1 Subwoofer
- Sound Enhancement: Digital Signal Processing, Subwoofer, Virtual 3D Surround
- Stereo System: NICAM
- Volume Control: Subwoofer Volume Control

Power

- Power supply: Built-in, 90-264 VAC, 50/60 Hz
- Consumption (On mode): < 100 W (< 62 W without subwoofer)
- Power LED indicator: Operation - green, Stand by/ sleep - Amber
- Complies with: Energy Star, NUTEK
- Consumption (Off Mode): < 2 W

Supported Display Resolution

- Computer formats: 640 x 480, 60, 75Hz, 720 x 400, 70Hz, 800 x 600, 60, 75Hz, 1024 x 768, 60, 75Hz, 1280 x 1024, 60, 75Hz
- Video formats: 480i, 25, 30Hz, 480p, 60Hz, 576p, 50Hz, 576i, 25, 30Hz, 720p, 50, 60Hz, 1080i, 25, 30Hz

Software

- Philips Sound Agent 2

Dimensions

- Box depth: 526 mm
- Set width (with stand): 590 mm
- Box height: 564 mm
- Set width (with stand) (inch): 23.2 inch
- Box width: 677 mm
- Set height (with stand): 451 mm
- Set height (with stand) (inch): 17.8 inch
- Set depth (with stand): 262.5 mm
- Set depth (with stand) (inch): 10.3 inch
- Temperature range (operation): 5°C to 35°C
- Temperature range (storage): -20°C to 60°C
- Box depth (inch): 20.7 inch
- Box height (inch): 22.2 inch
- Box width (inch): 26.7 inch
- Product weight (+stand): 9.5 kg
- Product weight (+stand) (lb): 20.9 lb
- Weight incl. Packaging: 14.5 kg
- Weight incl. Packaging (lb): 32
- Relative humidity: 20% - 80%
- MTBF: 50,000 hrs
- Subwoofer Weight: 4 kg
- Subwoofer Height: 220 mm
- Subwoofer Depth: 334 mm
- Subwoofer Width: 220 mm

Accessories

- Included accessories: AC Power Cord, Audio Cable, DVI-D cable, USB cable, VGA cable, 1x subwoofer
- User Manual
- Quick start guide



Issue date 2024-03-25

Version: 4.1.18

EAN: 87 10895 91278 5

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com