

Philips
Eye mask massager

16 silicone vibration contacts

2 temperature levels
3DSuite soft and fit
Mobile smart music

PPM2321



VibWave vibration massage, warm compress to relax

Gentle care, thoughtful vibration & hot compress

The product relieves eye fatigue through various methods of vibration and hot compress. Rich massage modes, suitable for different groups of people for eye relaxation. Smart connection function allows you to enjoy music at the same time.

Multiple massage techniques

- Knead and vibrate to moisten and soften eyes and aid sleep
- 3D contact vibration
- 4-point touch warm compress
- 5 major modes, you can choose according to your needs

Careful design and material selection

- Thumb-feeling silicone round head
- 3DSuit soft fit
- Lightweight soft shell material

Enjoy relaxation anytime

- Support mobile phone smart connection
- Built-in lithium battery, usable for 90 minutes

PHILIPS

Eye mask massager

16 silicone vibration contacts 2 temperature levels, 3DSuite soft and fit, Mobile smart music

Specifications

General specifications

- Product Dimension (LxWxH): 298×93×75 mm
- Net weight: approx.220g
- Massage type: Point vibration, Hot compress
- Main materials: Silicone
- Color: Dark blue

Main parameters

- Massage modes: 5
- Battery: 1200mAh
- Charging port: USB Type-C

- Charging Current: 550mA
- Charging Voltage: 5V
- Operating Power: 4W
- Operating Voltage: 3.7V

Country of origin

- Made in: China

Service

- Warranty period: 2 years

PPM2321DB/90

Highlights

4 functions in one

Knead with 16 large contact points, and apply evenly warm compress to wrap the eye area with delicate warmth. The soft, skin-friendly fabrics are comfortable to wear, and the sound effects are pleasant to fall asleep to. You can enjoy a new eye protection experience with one product for four functions.

VibWave multi-frequency vibration

Equipped with 16 independent VibWave vibration wave micro motors, it drives the massage contacts to vibrate in 3D waves to knead and compress the eye area, thereby achieving point-to-point delicate massage. Gentle and moderate, with even vibration, you can enjoy the moment of relaxation around the eyes.

4-point touch warm compress

It uses 4 large massage contact points under the orbit to generate heat instantly and evenly. Apply a warm compress around your eyes to relax your eyes in the warmth.

5 major modes

There are 5 preset modes, which can be applied to multiple scenes. You can switch between fast and slow frequency at will. There is always a set of settings that suits your needs and you can enjoy comfortable eye massage at any time.

Thumb-feeling silicone round head

Wrapped in skin-friendly silicone, when the contact points vibrate and knead, it is like gently massaging around the eyes with soft fingertips.

3DSuit soft fit

It adopts 3DSuit three-dimensional cutting, conforms to ergonomic design, and highly fits the contours of the face. The eye socket area is concave, allowing you to have a good sleep anytime and anywhere!

Soft shell material

The inner and outer layers are made of soft, skin-friendly fabrics with a warm and comfortable texture. The fiber is light and breathable. It won't tighten your eyes or make you stuffy, but will make you feel relaxed and comfortable.

Mobile smart connection

You can play the built-in light music of the product, or connect to your mobile phone to listen to your favorite songs. Listen to music and massage at the same time, let your mind be immersed in the beautiful rhythm, and enjoy the pleasant eye relaxation.

Battery for 90 mins use

Built-in 1200mAh large capacity battery. When fully charged, it can be used for about 90 minutes. Go out as you please and wherever you go.



Issue date 2024-04-02

Version: 1.1.1

EAN: 48 97126 05113 1

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com