

PHILIPS



Portable FM/AM
radio

FM/AM

Analogue tuning

AC or battery power



TAR2509

The classic companion

Love radio? From your kitchen to your garage and garden, this portable FM/AM analogue radio will keep your favourite stations playing. It sounds great, runs off AC or battery power and has a handy LED indicator—so you'll know when it's perfectly tuned.

Portable FM/AM radio

- Classic design, clear reception, easy tuning
- Analogue FM/AM radio
- Large traditional-style tuning window
- LED signal indicator

Clear sound for the stations you love

- Simple controls. Large volume dial
- Good, clear sound. 3.5" speaker
- Headphone port for private listening
- Switch between News and Music modes. Tone control

Easy to power wherever you listen

- Place it anywhere
- AC or battery operated (2 x D-sized batteries)
- Dimensions: 210 x 149.5 x 67 mm

Highlights

Classic design. Easy to tune



Analogue tuning makes it easy to find the stations you love on this portable FM/AM radio. Simply turn the tuning wheel on the side of the radio, and the large, clear window will show which frequency you're tuned to. An LED indicator lights up when the signal is strong.

Tone control



Make the most of your music with Music mode. Switch to News mode when you're listening to the news or your favourite radio soap or panel show. Whatever you love, the 3.5" speaker ensures good, clear sound.

Simple controls



You'll never need to search for the volume control on this radio! In addition to the large volume dial, the radio boasts top-mounted switches for switching between FM/AM signals and sound modes. You'll also find a headphone port for private listening.

Place it anywhere

Wherever you love to listen, this radio can come with you. Plug the radio into a wall socket or insert two D-sized batteries and go outside. It's the perfect companion for a glass of wine on the balcony or a picnic in the garden.

Specifications

Sound

Output power (RMS): 300 mW

Sound System: Mono

Sound enhancement: tone control

Volume control: rotary (analogue)

Loudspeakers

Full range driver diameter: 3.5"

Number of full range drivers: 1

Connectivity

Bluetooth: No

Audio/Video output: Headphone (3.5 mm)

Audio in: No

Tuner/Reception/Transmission

Tuner bands: FM, AM

RDS: No

Power

Battery type: D size (LR20)

Battery voltage: 1.5 V

Power supply: 220-240 V, 50/60 Hz

Number of batteries: 2

Packaging dimensions

Height: 19.3 cm

Packaging type: Box

Type of shelf placement: Laying

Width: 29 cm

Depth: 9.3 cm

Number of products included: 1

Gross weight: 1.1 kg

Net weight: 0.885 kg

Tare weight: 0.215 kg

Product dimensions

Height: 14.95 cm

Width: 21 cm

Depth: 6.63 cm

Weight: 0.668 kg

Accessories

Included accessories: AC Power Cord, Quick start guide, Warranty certificate

Alarm

No. of alarms: No

Snooze (repeat alarm): No

