



Philips Ultinon
WeatherVision
Car headlights bulb

LED-HL Fog [≈H8/H9/H16]

Direct-fit LED bulb
3500 K warm white light
Advanced automotive system



11366U2510X2

Drive safely through any weather

Halogen color match, easy install, LED performance

"Switch your vehicle's headlights to Philips Ultinon WeatherVision LED and experience better contrast on the road plus the performance of LEDs! These easy-to-install bulbs mean you can now upgrade to LEDs without the fuss!*"

3500K classic white light

- Enjoy the 3500K warmth of classic light

Better light performance

- Better light-beam performance than halogen**

Quick, easy installation

- Plug-and-play installation

Reliable Philips quality

- Automotive-standards compliant
- Long-lasting performance

PHILIPS

Car headlights bulb

LED-HL Fog [$\approx$ H8/H9/H16] Direct-fit LED bulb, 3500 K warm white light, Advanced automotive system

Specifications

Marketing specifications

- Product highlight: Direct-fit LED bulb
- Expected benefits: Quick, easy installation

Product description

- Application: Fog
- Base: PGJ19-1/3/5
- Designation: LED Fog 11366 U2510 12V20W X2
- Designation LED Type: [$\approx$ H8], [$\approx$ H9], [$\approx$ H16]
- Operating Temperature: -40°C / +85°C
- Range: Ultinon WeatherVision
- Technology: LED
- Type: H8, H9, H16
- Homologation ECE R37: No
- Homologation ECE R10
- Polarity free

Lifetime

- Life time: 1500 hours

Light characteristics

- Lumens: 1800 lm
- Color temperature: 3500 K

Electrical characteristics

- Voltage range: 12V
- Wattage: 20W

Ordering information

- Order entry: 11366U2510X2
- Ordering code: 72919031

Packaging Data

- EAN1: 6974260729190
- EAN3: 6974260729206

Packed product information

- Gross weight per piece: 100.15g g
- Length: 4.8cm cm
- Width: 10.2cm cm
- Height: 10.6cm cm
- Net weight per piece: 34.2g g
- Pack Quantity: 2 pcs
- MOQ (for professionals): 6 sets

Outerpack information

- Length: 15.5cm cm
- Width: 11cm cm
- Height: 22cm cm
- Gross weight per piece: 0.73kg kg

LUM11366U2510X2/20

Highlights

3500K warm white light

Philips Ultinon WeatherVision LED bulbs project an elegant, halogen-like glow at 3500 Kelvin. They give your car a timeless style while offering the extra brightness of LED. Experience more comfortable vision in difficult weather conditions, such as snow and fog, thanks to reduced glare.

Beam outperforms halogen

Delivering superior light-beam performance, Philips Ultinon WeatherVision LED bulbs outshine halogen bulbs and feature a compact, universally compatible design. Using the latest innovations in LED technology, they match standard ECE halogen brightness while enhancing beam efficiency with reduced energy consumption. Philips Ultinon WeatherVision LED bulbs provide drivers with better on-road vision, making it easier to spot obstacles and drive more safely.

Plug-and-play installation

"With Philips Ultinon WeatherVision LED bulbs, installation is so quick and easy that retrofitting them is child's play! There's no need for compatibility checks or adapter rings: Philips Ultinon WeatherVision LED bulbs come with an ultra-compact body and an integrated IEC 60061-compatible base. Their direct-fit design features the same footprint as halogen bulbs, enabling straightforward installation in tight spaces. They fit easily and ensure broad compatibility with most vehicle models*."

Automotive-standards compliant

Technologically advanced, Philips lighting has been renowned in the automotive industry for over 100 years. Aware that the performance of our products depends on their compatibility with the demands of today's automotive environment, we design our products as closely as possible to industry standards. Our Philips Ultinon WeatherVision LED bulbs comply with EMI standards for electromagnetic interference. Precision-engineered to withstand the rigors of modern automotive life, our bulbs won't disrupt the operation of other vehicle components.

Long-lasting performance

Philips Ultinon WeatherVision LED bulbs are rigorously tested and checked to ensure long-term durability and long-lasting performance. Our range offers up to three times the life of a comparable halogen bulb and homogeneous light throughout the bulbs lifespan. The Philips warranty policy covers Philips Ultinon WeatherVision LED bulbs.*** Enjoy the best of today's technology with Philips Ultinon WeatherVision LED bulbs.



Issue date 2024-04-07

Version: 2.2.1

EAN: 69 74260 72919 0

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* It is your own responsibility to ensure that the use of the LED retrofit lights complies with applicable local legal requirements. The lamps are not permitted for use on public roads.
* ** Compared to the legal minimum for halogen bulbs
* *** 2-year standard.