

Philips  
Multimedia Speaker 5.1



SPA7650

## Hi-Fi surround sound

### 5.1 Surround Sound

Connect these multimedia speakers to any PC, MP3 or CD player and instantly create your own 5.1 surround sound system. The superb bass is easily adjustable and you can set the speakers up on your desk or on the wall to get that perfect sound.

#### Ultimate bass performance

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Bass boost technology with level control
- Wooden housing for quality bass reproduction

#### Easy to use

- Magnetic Shielding eliminates computer screen distortion
- Headphone jack for better personal music enjoyment
- Remote volume control for convenient sound adjustment
- Plug and Play for easier installation

#### Connect to all your gear

- Additional headphone connection for personal listening
- Unique direct MP3 input via your RC
- Perfect for MP3, PC, TV, CD and more

#### Contemporary design

- Attractive high gloss finish

# PHILIPS

# Highlights

## Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

## Bass with level control

Unique subwoofer design produces a much deeper, richer bass. You also have the option to set the bass level to your choice.

## Perfect for MP3, PC, TV and more

Connect your speakers to all your gear. A great way to listen to your MP3 player, PC, TV, CD, DVD and all your multimedia stuff.

## High gloss finish

High-gloss 'Piano black' finish looks simply superb in both classic and modern interiors.

## Headphone connection

This speaker system features an additional headphone connection. Connect your own headphones for a more personal listening experience whenever you want it.

## Headphone jack

Headphone jack for better personal music enjoyment

## Magnetic Shielding

Because the powerful magnets in speaker drivers are magnetically shielded, there is no

danger of image distortion or damage when placed close to your PC monitor screen.

## MP3 input via your RC

Thanks to the unique direct MP3 input on the remote control you can easily listen to your MP3 player. Simply connect the audio output of your MP3 player to the 3.5 mm jack on the remote control and enjoy your music.

## Plug and Play

Plug and Play gives you the ability to install or add a new component and have it work without having to perform any complex installation procedures or technical analyses.

## Remote volume control

The handy wired remote control allows you to set the volume level at your finger-tips.

## Wooden subwoofer

The housing of the subwoofer is made from wood, giving it superior stability and acoustic performance.



# Specifications

## Sound

- Bass enhancement: Bass reflex, Dynamic Bass Boost
- Output power (RMS): 4 x 12.5 W + 15 W (centre speaker) + 25 W

## Loudspeakers

- Loudspeaker Enhancement: Magnetic Shielded LSB
- Satellite speaker freq range: F0 - 20k Hz
- Subwoofer freq range: F0 - 2k Hz
- Satellite speaker drivers: 2"
- Subwoofer driver: 5 1/4"
- Subwoofer type: Active
- Bass level control: On rear side of subwoofer
- Subwoofer impedance: 8 ohm
- Power on/off button: On rear side of subwoofer

## Connectivity

- Audio input for data: Stereo Audio (3.5 mm jack) 1 x

## Outer Carton

- EAN: 87 12581 43484 7
- Length: 45.8 cm
- Number of consumer packages: 2
- Width: 31 cm
- Gross weight: 17.7 kg
- Height: 61 cm
- Net weight: 14.4 kg
- Tare weight: 3.3 kg

## Convenience

- Ease of Installation: Plug and Play

- Power on indication
- Remote control: volume control, headphone output, additional audio input, power indicator

## Power

- Power LED indicator: Blue

## Packaging dimensions

- Height: 44.6 cm
- Packaging type: Carton
- Type of shelf placement: Laying
- Width: 29.6 cm
- Depth: 29.8 cm
- Number of products included: 1
- EAN: 87 12581 43466 3
- Gross weight: 8.3 kg
- Net weight: 7.2 kg
- Tare weight: 1.1 kg

## Product dimensions

- Cable length: 0 cm
- Height: 0 cm
- Width: 0 cm
- Depth: 0 cm
- Weight: 0 kg

## Packaging content

- Subwoofer
- Number of satellites: 5
- 3.5 mm stereo line cable
- Quick installation guide
- Remote Control: Wired



Issue date 2024-04-13

Version: 4.1.7

EAN: 87 12581 43466 3

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)