



Philips  
Professional Soundbar

**2.1 Soundbar**  
with built-in subwoofer



HAL5023

## Immersive TV Sound Experience

With built-in subwoofer

This sound enhancing subwoofer will extend the experience for guests using Philips MediaSuite TVs. Easy to install, set up and control, with a built-in subwoofer designed to add extra punch to special effects, music and more.

### Professional and managed

- Easy setup and cloning via the professional TV menu
- Smart power cable for quick installation
- Customisable sound configuration
- Controlled clearing of Bluetooth connections
- Control the soundbar with the TV remote control
- Freedom of placement — whether wall mounted or placed on a surface
- Anti-theft provision
- Professional warranty

### A superior TV sound to match the content of choice

- More powerful TV sound
- Play your personal sound content via Bluetooth Audio

**PHILIPS**

# Specifications

## Convenience

- Wall mountable
- Anti-theft provision: Cable

## Sound

- Equalizer settings: Movie, Music, Voice, Stadium
- Speaker output power: 200 W max/100 W RMS (10 % THD)
- Speaker configuration: 2.1 (2 x 2" + 1 x 3")

## Connectivity

- Bluetooth: SBC, A2DP
- Bluetooth version: 4.2
- Number of HDMI connections: 1
- HDMI features: Audio Return Channel, EasyLink (HDMI-CEC), HDMI 1.4

## Power

- Power supply: 100-240 VAC, 50/60 Hz
- Power consumption: 30 W
- Standby power consumption: < 0.5 W

## Accessories

- Included: Wall-mount bracket (2 pcs), Y-shaped power cord adapter, HDMI Cable, Warranty Leaflet

## Dimensions

- Packaging dimensions (WxDxH): 91.5 x 18 x 13 cm
- Gross weight: 3.8 kg
- Product weight: 2.5 kg
- Product dimensions (WxDxH): 70 x 12 x 7 cm

## Packaging Data

- EAN: 87 18863 03997 7

## Outer Packaging

- GTIN: 1 87 18863 03997 4
- Number of trade items: 4
- Outer carton (W x H x D): 94 x 29 x 38.5 cm
- Gross weight: 16.5 kg
- Net weight: 12 kg
- Tare weight: 4.5 kg

## Supported by

- B-line 2000-series: BFL2114 BFL2214
- MediaSuite 5000-series: HFL5014 HFL5114 HFL5214
- MediaSuite 6000-series: HFL6014 HFL6114 HFL6214

# Highlights

## Powerful TV sound

Hear more in everything you watch and every track you love. 2.1 channels bring out the best in effects, score and dialogue. The built-in subwoofer lets you feel the bass, whether you're listening to music or watching an action film.

## Bluetooth audio

Link your mobile device via Bluetooth and play your favourite soundtracks with the soundbar's enhanced sound performance.

## Easy setup and cloning

Easily configure the soundbar settings through the professional setup menu on the MediaSuite TV. All related settings can be copied and transferred to other TVs through cloning.

## Smart power cable

With the specially designed power cable adapter, only one power socket is needed to power both the soundbar and the TV.

## Customisable sound configuration

Choose the best sound settings for the best sound experience. As you are in control of the professional settings, you can set the default level and maximum volume limit, amongst other things. The chosen default configuration will be reset for each new user.

## Controlled clearing

When clearing user data on the TV, this ensures that Bluetooth pairing information from any mobile devices used will also be cleared.

## TV remote control

No dedicated remote control required. Conveniently control the soundbar volume with the TV remote control.

## Freedom of placement

Conveniently placed on a surface or mounted with the included wall brackets, the sleek trapezoid design looks great in any setting.

## Anti-theft

Discourage unauthorised removal of the device with the included anti-theft cable.

## Professional warranty

A professional device warrants a professional warranty: 3 years.

