

# PHILIPS



## Soundbar 2.1 with wireless subwoofer

2.1 Ch, wireless subwoofer

240 W max. HDMI ARC

DTS Virtual:X

Dolby Digital Plus



TAB5309

## Better, deeper sound for all your entertainment

Bring movies and more to life with this powerful soundbar and wireless subwoofer. Explosions will rumble. Music will sing. Games get more epic. Sophisticated audio technology creates an immersive sound experience no matter what you watch.

### Philips essential 2.1 soundbar

- Deeper TV sound. 240 W max
- 2.1 channels. Wireless subwoofer for deeper bass
- Looks great, and it's easy to place

### Immersive sound for everything you love

- DTS Virtual:X for immersive 3D sound in any room
- Dolby Digital Plus. Cinematic sound at home
- Four EQ sound modes and dialogue enhancement

### Easy control, all the connections

- Control your soundbar and TV with a single remote
- Connect your favorite sources for bigger sound
- Bluetooth 5.4 with LE Audio support
- HDMI ARC, optical connection, AUX-in, USB
- Philips Home Entertainment app

# Highlights

## 2.1 channels with subwoofer



2.1 channels and immersive audio technology bring you new levels of sound, while the compact wireless subwoofer adds satisfying weight to effects and music. Four EQ modes let you pick a sound style to suit what you're watching—and voices get clearer in any mode if you activate Dialogue Enhancement.

## DTS Virtual:X



Compatibility with DTS Virtual:X transforms your TV sound, bringing you a virtual 3D sound experience no matter what's on screen! You don't need extra speakers, and it works in any room: turn it on via the soundbar's remote control, or the Philips Home Entertainment app.

## Dolby Digital Plus



Enjoy a front-row seat to all the dramas you watch and play. This Dolby Digital Plus-compatible soundbar gives you a surround-sound experience without the need for extra speakers. You'll hear, and feel, the difference.

## Easy placement



This sleek soundbar looks great in any room and its compact subwoofer is easy to conceal. Got your TV on the wall? You can use the detachable brackets (included) to wall-mount this soundbar too.

## HDMI ARC and Philips EasyLINK



You can adjust the volume on your soundbar using your TV remote. If you have a Philips Ambilight TV, the EasyLINK function lets you use the remote to switch between the soundbar's preset EQ modes, adjust bass and treble—and more.

## Easy connections



Compatibility with Bluetooth LE Audio gives you a steadier connection, better sound, and less lag if you're streaming playlists from a smart device that is also compatible with Bluetooth LE Audio. You can also connect audio sources to the soundbar via audio-in, USB, or optical input.

## Philips Home Entertainment app

Download the app and you can use your smart device to switch between the EQ sound modes, select source, activate virtual surround sound, and more.

# Specifications

### Sound

**Sound Enhancement:** Audio sync, Auto Volume Leveler, Treble and Bass Control  
**Equalizer settings:** Movie, Music, Voice, Stadium  
**Total harmonic distortion:** <=10%  
**Speaker system output power:** 240W max / 120W RMS

### Loudspeakers

**Subwoofer freq range:** 40 - 150 Hz  
**Subwoofer type:** Active, Wireless subwoofer  
**Subwoofer impedance:** 4 ohm  
**Number of sound channels:** 2.1  
**Number of woofers:** 1  
**Woofer diameter:** 5.25"  
**Soundbar freq range:** 150 - 20K Hz  
**Soundbar impedance:** 8 ohm  
**Front drivers:** 2 full range (L+R)  
**External subwoofer enclosure:** Bass reflex

### Connectivity

**Bluetooth:** Receiver  
**Bluetooth version:** 5.4  
**Bluetooth profiles:** A2DP, AVRCP  
**EasyLink (HDMI-CEC)**  
**USB playback**  
**Audio in:** 1x 3.5mm  
**Optical input x 1**  
**HDMI content protection:** HDCP 1.4  
**HDMI Out (ARC) x 1**  
**DLNA Standard:** No  
**Multiple speaker connection:** No  
**Smart Home:** None  
**Wireless speaker connection:** Subwoofer

### Supported Audio Formats

**Bluetooth:** SBC  
**HDMI ARC:** Dolby Digital, Dolby Digital plus, LPCM 2ch, DTS Digital Surround (DTS 5.1), DTS Virtual:X  
**USB:** MP3, WAV, FLAC  
**Optical:** Dolby Digital, LPCM 2ch

### Outer Carton

**Length:** 92 cm  
**Number of consumer packagings:** 2  
**Width:** 48.5 cm  
**Gross weight:** 15.5 kg  
**Height:** 24.5 cm  
**Nett weight:** 10.10 kg  
**Tare weight:** 5.40 kg

### Convenience

**EasyLink (HDMI-CEC):** Audio Return Channel, Automatic audio input mapping, One touch play, System standby  
**Remote Control**  
**Night mode**

### Compatibility

Smartphone/tablet APP control

### Power

**Power LED indicator**  
**Main unit power supply:** 100-240V AC, 50/60 Hz  
**Subwoofer power supply:** 100-240V AC, 50/60 Hz  
**Subwoofer standby power:** < 0.5 W  
**Main unit standby power:** < 0.5 W  
**Auto standby**

### Packaging dimensions

**Height:** 22.5 cm  
**Packaging type:** Box  
**Type of shelf placement:** Laying  
**Width:** 90 cm  
**Depth:** 33.5 cm  
**Number of products included:** 1  
**Gross weight:** 7.09 kg  
**Nett weight:** 5.05 kg  
**Tare weight:** 2.04 kg

### Accessories

**Included accessories:** Remote Control, 2 x AAA Batteries, Power cord, Wall mount bracket, Quick start guide, Warranty Card

### Design

**Color:** Dark grey  
**Wall mountable**

### Dimensions

**Main Unit (W x H x D):** 766 x 67.3 x 91 mm  
**Main Unit Weight:** 1.6 kg  
**Subwoofer (W x H x D):** 195 x 315.5 x 195 mm  
**Subwoofer Weight:** 3.03 kg

### Video

**3D pass-through:** No

