

Philips
True Wireless
Headphones

Clear call quality

Touch control
Ergonomic design for comfort
IPX4 splash/sweat resistant

TAT1158GR



Hear your sounds clearly

Hear your sounds perfectly. These True Wireless headphones use 13 mm drivers for lush sound and punchy bass and an AI mic for clear calls. With IPX4 splash and sweat resistance and a pocket-sized charging case for 21 hours play time.

Active all day

- IPX4 splash and sweat resistant

Powerful playlists. Clear calls

- Custom 13 mm drivers for lush sound and punchy bass
- AI mic for clear call quality

Listen for longer

- Lightweight design for comfortable secure fitting

Ready for you

- No worries. Up to 21 hours play time with the case

PHILIPS

True Wireless Headphones

Clear call quality Touch control, Ergonomic design for comfort, IPX4 splash/sweat resistant

Specifications

Sound

- Frequency range: 20 - 20,000 Hz
- Speaker diameter: 13mm
- Impedance: 32 Ohm
- Sensitivity: 96 dB(1K Hz)
- Driver type: Dynamic

Connectivity

- Bluetooth version: 5.3
- Wireless
- Bluetooth profiles: A2DP, AVRCP, HFP
- Maximum range: up to 10 m
- Supported codec: SBC
- Type of wireless transmission: Bluetooth

Outer Carton

- Length: 29.1 cm
- Number of consumer packagings: 24
- Width: 25.1 cm
- Gross weight: 4.069 kg
- Height: 28.7 cm
- GTIN: 1 48 95229 14827 4
- Nett weight: 1.176 kg
- Tare weight: 2.893 kg

Convenience

- Automatic power off
- Volume control
- Water resistance: IPX4

Inner Carton

- Length: 13.7 cm
- Number of consumer packagings: 3
- Width: 11.7 cm
- Height: 12.9 cm
- Nett weight: 0.147 kg
- Gross weight: 0.46 kg
- Tare weight: 0.313 kg
- GTIN: 2 48 95229 14827 1

Power

- Rechargeable
- Music play time: 6+15 hour(s)
- Charging time: 1.5 hour(s)
- Battery type(Charging case): Lithium Polymer (built-in)
- Battery type(Earbud): Lithium Polymer (built-in)
- Battery capacity(Case): 350 mAh
- Battery capacity(Earbud): 40 mAh

Packaging dimensions

- Height: 14 cm
- Packaging type: Carton
- Type of shelf placement: Standing
- Width: 11 cm
- Depth: 4.2 cm
- Number of products included: 1
- EAN: 48 95229 14827 7
- Gross weight: 0.135 kg
- Nett weight: 0.049 kg
- Tare weight: 0.086 kg

Accessories

- Quick Start Guide
- Charging case
- Charging cable: USB-C cable, 250mm

Design

- Color: Green
- Ear fitting: In-ear
- In-ear fitting type: Open fit

Telecommunication

- Microphone for call: 1

Voice assistant

- Voice assistant compatible: Apple Siri
- Voice assistant activation: Manual
- Voice assistant support

TAT1158GR/97

Highlights

13 mm dynamic drivers

Hear your sounds the way they were meant to be heard. These headphones use custom design, 13 mm dynamic drivers to bring you an amazing listening experience. The drivers' large power capacity enhances dynamics and bass so you'll never miss a beat.

21 hours play time with case

You get 7 hours play time from a full charge, and an extra 14 hours from the case. Pop the earbuds back in the case and they'll recharge fully in 2 hours. If you need a quick boost, just 15 minutes gives you an extra hour. The case can be charged via USB-C.

Clear call quality

Don't let sounds from the world interrupt your listening. These headphones feature an AI microphone that uses an advanced AI algorithm to filter out the noise you don't want to hear and ensure clear call quality. Hear each other clearly every time.

IPX4 splash/sweat resistant

An IPX4 rating and powerful 13 mm drivers let you enjoy great sound in any weather. The headphones are splash resistant and won't mind a little rain or sweat so you don't need to worry about getting caught in a shower.

Lightweight design for comfort

Lightweight design for comfortable secure fitting



Issue date 2024-06-28

Version: 2.2.1

EAN: 48 95229 14827 7

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com