

Philips  
Open-ear wireless sports  
headphones

**Open-ear fit**  
Clear call quality

TAT3708BK



## Free your ears. Hear it all.

These open-ear wireless headphones let you hear everything that's going on around you- and your music too.

### **Hear differently**

- Sound without earphones. Open-ear design
- Balanced sound wherever you are

### **Active all day**

- IPX4 splash and sweat resistant

### **Powerful playlists. Clear calls**

- AI mic for clear call quality

# PHILIPS

Open-ear wireless sports headphones  
Open-ear fit Clear call quality

# Specifications

## Sound

- Frequency range: 20 - 20,000 Hz
- Speaker diameter: 13 mm
- Impedance: 20 Ohm
- Maximum power input: 5 mW
- Sensitivity: 92 dB (1K Hz)
- Driver type: Dynamic

## Connectivity

- Bluetooth version: 5.4
- Wireless
- Bluetooth profiles: A2DP, HFP, AVRCP
- Supported codec: SBC
- Type of wireless transmission: Bluetooth

## Outer Carton

- Length: 42.8 cm
- Number of consumer packagings: 60
- Width: 41.3 cm
- Gross weight: 11.9 kg
- Height: 29.00 cm
- GTIN: 14895229149554

## Convenience

- Volume control
- Water resistance: IPX4
- Type of controls: Touch

## Power

- Number of batteries: 3 pcs
- Music play time: 6 + 16 hour(s)
- Charging time: 2 hour(s)
- Battery type(Charging case): Lithium Polymer (Built-in)
- Battery type(Earbud): Lithium Polymer (Built-in)

- Battery capacity(Case): 300 mAh
- Battery capacity(Earbud): 45 mAh

## Packaging dimensions

- Height: 13.4 cm
- Packaging type: Box
- Type of shelf placement: Hanging
- Width: 13.4 cm
- Depth: 4.1 cm
- Number of products included: 1
- EAN: 4895229149557
- Gross weight: 0.14 kg
- Nett weight: 0.075 kg
- Tare weight: 0.065 kg

## Accessories

- Quick Start Guide
- Charging case
- Charging cable: USB-C cable

## Design

- Color: Black
- Wearing style: Ear-hook
- In-ear fitting type: Open fit

## Telecommunication

- Microphone for call: 1 AI mic

## Dimensions

- Charging case dimension(WxDxH): 9.35\*5.0\*2.91 cm
- Earbud dimension(WxDxH): 5.0\*2.05\*3.55 cm
- Total weight: 0.05 kg

## Voice assistant

- Voice assistant support

TAT3708BK/97

# Highlights

## Balanced sound everywhere

These headphones feature an Adaptive Equal Loudness Compensation (AELC) algorithm. This adjusts the treble and bass so that whether you're outside with the volume up or inside with the volume down, you'll always hear clear, balanced sound.

## Clear call quality

Don't let sounds from the world interrupt your listening. These headphones feature an AI microphone that uses an advanced AI algorithm to filter out the noise you don't want to hear and ensure clear call quality. Hear each other clearly every time.

## IPX4 splash/sweat resistant

An IPX4 rating and powerful 13 mm drivers let you enjoy great sound in any weather. The headphones are splash resistant and won't mind a little rain or sweat so you don't need to worry about getting caught in a shower.

## Directional Acoustic design

With specialized chamber and algorithm, Directional Acoustic technology beams music into your ear canal, minimizing leakage and vibration and retaining detail and bass. All the benefits of an open-ear design with improved sound quality and comfort.



Issue date 2024-07-25

Version: 3.3.1

EAN: 48 95229 14955 7

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)