

Philips
Open-ear wireless sports
headphones

Open-ear fit
Clear call quality

TAA1708BK



You move, they won't

These open-ear wireless headphones let you hear everything that's going on around you- and your music too.

Active all day

- IPX4 splash and sweat resistant

Hear differently

- Sound without earphones. Open-ear design
- Balanced sound wherever you are

Powerful playlists. Clear calls

- AI mic for clear call quality

PHILIPS

Open-ear wireless sports headphones
Open-ear fit Clear call quality

Specifications

Sound

- Frequency range: 20~20kHz
- Speaker diameter: 16 mm
- Impedance: 16 ohms
- Sensitivity: 98 dB(1 KHz) dB
- Driver type: Dynamic

Connectivity

- Bluetooth version: 5.4
- Wireless
- Bluetooth profiles: HFP, A2DP, AVRCP
- Maximum range: max 10 m
- Supported codec: SBC
- Type of wireless transmission: Bluetooth

Outer Carton

- Length: 51.5 cm
- Number of consumer packagings: 60
- Width: 42.5 cm
- Gross weight: 10.76 kg
- Height: 33.5 cm
- GTIN: 1 48 95229 15203 5

Convenience

- Volume control
- Water resistance: IPX4
- Type of controls: Button

Power

- Battery type: Lithium-ion (built-in)
- Rechargeable
- Number of batteries: 1
- Music play time: 8 hour(s)

- Charging time: 2 hour(s)
- Battery capacity(Headphones): 140 mAh

Packaging dimensions

- Height: 19 cm
- Packaging type: Box
- Type of shelf placement: Hanging
- Width: 13.5 cm
- Depth: 5 cm
- Number of products included: 1
- EAN: 48 95229 15203 8
- Gross weight: 0.1 kg
- Nett weight: 0.035 kg
- Tare weight: 0.065 kg

Accessories

- Others: Quick start guide
- Quick Start Guide
- Charging case
- Charging cable

Design

- Color: Black
- In-ear fitting type: Open fit

Telecommunication

- Microphone for call: 1 AI mic

Voice assistant

- Voice assistant compatible
- Voice assistant activation: Press Multi-Function button
- Voice assistant support

TAA1708BK/97

Highlights

IPX4 splash/sweat resistant

An IPX4 rating and powerful 16 mm drivers let you enjoy great sound in any weather. The headphones are splash resistant and won't mind a little rain or sweat so you don't need to worry about getting caught in a shower.

Balanced sound everywhere

These headphones feature an Adaptive Equal Loudness Compensation (AELC) algorithm. This adjusts the treble and bass so that whether you're outside with the volume up or inside with the volume down, you'll always hear clear, balanced sound.

Clear call quality

Don't let sounds from the world interrupt your listening. These headphones feature an AI microphone that uses an advanced AI algorithm to filter out the noise you don't want to hear and ensure clear call quality. Hear each other clearly every time.

Directional Acoustic design

With specialized chamber and algorithm, Directional Acoustic technology beams music into your ear canal, minimizing leakage and vibration and retaining detail and bass. All the benefits of an open-ear design with improved sound quality and comfort.



Issue date 2024-08-05

Version: 4.4.1

EAN: 48 95229 15203 8

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com