



Philips  
Over ear headphones

50 mm neodymium drivers  
Open-back design  
3m removable cable

**SHP9600**

## A quality performance

Looking for the perfect blend of performance, comfort, and quality? These over-ear, open-back headphones are built to take your home listening up a notch. You get great sound, premium construction, and gold-plated cable connections.

### **Comfort fit**

- Adjustable steel headband. Double-layered headband cushion
- Angled acoustic drivers fit your ear's natural geometry
- Superb comfort and durability
- Light, breathable ear-cup cushions. For long listening

### **Beautiful sound for all your music**

- 50 mm neodymium drivers. Perfectly tuned
- Crisp bass. Balanced midrange. Pristine high frequencies
- Open-back design. Spacious sound

### **Immerse in any source**

- Connect to any source. From phone to headphone amp
- 3 m removable cable. Gold-plated 3.5-6.3 mm adapter

**PHILIPS**

Over ear headphones  
50 mm neodymium drivers Open-back design, 3m removable cable

# Specifications

## Sound

- Acoustic system: Open
- Frequency range: 6 - 35,000 Hz
- Speaker diameter: 50 mm
- Impedance: 32 Ohm
- Maximum power input: 200 mW
- Sensitivity: 102 dB (1K Hz)
- Distortion (THD): <math>\leq 0.1\%</math> THD
- Driver type: Dynamic

## Connectivity

- Finishing of connector: gold-plated
- Detachable cable
- Headphone socket: 3.5 mm

## Outer Carton

- Length: 37.5 cm
- Number of consumer packagings: 3
- Width: 21 cm
- Gross weight: 2.27 kg
- Height: 23.5 cm
- GTIN: 1 48 95229 10840 7
- Nett weight: 0.876 kg
- Tare weight: 1.394 kg

## Packaging dimensions

- Height: 22.5 cm
- Packaging type: Box

- Type of shelf placement: Hanging
- Width: 19.5 cm
- Depth: 12 cm
- Number of products included: 1
- EAN: 48 95229 10840 0
- Gross weight: 0.632 kg
- Nett weight: 0.292 kg
- Tare weight: 0.34 kg

## Product dimensions

- Height: 20.1 cm
- Width: 17.2 cm
- Depth: 10 cm
- Weight: 0.292 kg

## Accessories

- Audio cable: 3.5mm stereo cable, L=3m
- Included adapters: 3.5-6.3 mm adapter plug

## Design

- Color: Black
- Wearing style: Headband
- Ear coupling material: Fabric
- Ear fitting: Over-ear
- Earcup type: Open-back

## UPC

- UPC: 8 40063 20141 5

SHP9600/00

# Highlights

## Open-back design.



Feel the music. Perfectly tuned 50 mm drivers deliver crisp bass, balanced midrange, and pristine high frequencies. The drivers are engineered to fit the ear's natural geometry, ensuring no detail is lost.

## Superb comfort and durability



The headband is reinforced with durable steel, which adds just the right amount of tension for a secure fit. The double-layered headband cushion adds real comfort, and the breathable ear-cup cushions are perfect for long listening sessions.

## Connect to any source.



Immerse in your favorite albums on your smart device, home setup, TV, or laptop. The included cable boasts a gold-plated 6.3-3.5 mm jack adapter for the best connection when listening on audiophile-grade equipment.



Issue date 2024-08-12

Version: 5.2.6

EAN: 48 95229 10840 0

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Battery life of playtime is approximate and may vary depending on application condition.