

PHILIPS

LED Motorcycle
headlight bulb

Ultinon Pro6000
moto

Road-legal LED

H4-LED

Up to 230% brighter light**

Lumileds automotive LEDs

LUM11342U6000X1



Upgrade to road-legal LED* for superior visibility

The perfect blend of performance and durability

Experience an unprecedented driving experience with Philips' road-approved* LED headlight bulbs. With up to 230% brighter light** and a daylight-like white beam, these LED bulbs illuminate everything clearly without dazzling oncoming drivers.

High-quality LED lighting

- Philips automotive lighting for the highest quality

Road-legal LED

- Road-legal LED upgrade bulbs

Enhanced fit with compact design

- Compact all-in-one design for easy installation

Superior brightness

- Reliable illumination and improved visibility
- Perfect beam for a safer driving

Long-lasting performance

- Built to last up to 3000 hours

Ultinon Pro6000 moto

LED Motorcycle headlight bulb

Specifications

Marketing specifications

Expected benefits: Brighter Lights, Improved visibility, Long-lasting performance
Product highlight: Road-legal LED bulb, Automotive Grade LED

Product description

Application: Motorcycle Lighting, High beam, Low beam functions
Base: P43t-38
Designation: LED H4 11342 U6000 X1
Designation LED Type: H4-LED
ECE certification: NO
Ingress protection rating (IP): IP55
Operating temperature: -40 to +105°C
Range: Ultinon Pro6000
Technical features: Road-legal LED, AirFlux+, SafeBeam Technology
Technology: LED
Type: H4
Compatible with: Applicable only for car models listed in the Philips compatibility list*

Lifetime

Life time: 3000 hrs

Light characteristics

Colour temperature: 5800 K
Lumens: 1000/1650 lm

Electrical characteristics

Wattage: 18 W
Voltage range: 9 - 36 V
Rated voltage [V]: 12 V

Ordering information

Order entry: 11342U6000X1
Ordering code: 2422094

Packaging Data

Packaging type: X1
EAN1: 8719018024220
EAN3: 8719018024237

Packed product information

Length: 4.5 cm
Width: 13.5 cm
Height: 5.5 cm
Net weight per piece: 91 g
Pack Quantity: 1 pc
MOQ (for professionals): 4 pcs (4 sets)
Gross weight per piece [g]: 119 g

Outer pack information

Length: 11.8 cm
Width: 15 cm
Height: 23.6 cm
Gross weight per piece [kg]: 0.555 kg

LUM11342U6000X1

Highlights

Safe, homologated LED light

We are bringing our long expertise to riders with our Philips Ultinon Pro6000 H4-LED bulbs, 100% road-legal* and homologated by the Ministry of Transport for use on public roads and for selected motorbike and motorcycle models. You can now convert the low beam of your halogen headlights to our tested, safe and road-approved* Philips Ultinon Pro6000 H4-LED lights to enjoy reliable illumination and an unrivalled LED driving experience. Visit our Philips.com/roadlegalLED page* for further information.

Up to 230% brighter light**

Reliable illumination and improved visibility

Experience improved visibility

Perfect beam for a safer driving

5800 K for crisp white light

With a colour temperature of up to 5800 Kelvin, the Philips Ultinon Pro6000 LED bulbs produce a bright white light. The clearer vision this provides makes it easier to spot obstacles and enhances contrasts. The optimal colour temperature avoids tiring or straining the eyes, giving you more comfortable and safer night-time driving.

Compact all-in-one design

The brand-new design of the Philips Ultinon Pro6000 H4-LED takes up little space in the headlight. Thanks to its one-piece design and integrated driver, the installation is simple and easy. These Philips Ultinon Pro6000 H4-LED bulbs are compatible with a range of selected motorcycle models*. For further information, visit Philips.com/roadlegalLED.

Up to 3 years' warranty***

You want bright, stylish headlights but you don't want to keep replacing failed lights. LED bulbs generate heat that must be managed. Advanced AirBoost technology and a built-in fan for active cooling contribute to long-lasting reliability. This unique system diverts heat away from the bulb's critical components and enables Philips Ultinon Pro6000 H4-LED bulbs to last longer, providing up to 3000 hours of use. Visit philips.com/auto-warranty to register for an extended warranty***.

Highest quality lighting

Philips automotive lighting for the highest quality

