



Philips Philips  
RO Water Station

Aquaporin Inside® technology

All-in-one integrated filter  
Instant heating  
No installation required

ADD6901HBK01

## Easy access to clean drinking water

With all-in-one integrated filter

With instant heating technology, this RO water dispenser provides water of various temperatures within seconds. The innovative AquaShield all-in-one RO filtration removes 110 kinds of harmful substances that may exist in tap water\*.

### **RO filtration removes 110 kinds of harmful substances**

- RO filtration removes 110 kinds of harmful substances\*
- Fresh hot water on demand in 3 seconds
- 4 preset temperatures for your different needs
- 4 preset water volumes for your different needs
- 2000 L filtration capacity
- Safety lock to prevent incorrect use or burning
- ClearSmart intelligent system
- Plug and play; no installation required

# PHILIPS

# Specifications

## Filtration performance

- Filtration level: 5-stage
- Water hardness reduction
- Pesticides reduction
- Lead reduction
- PFOA reduction
- Recommended filter lifetime: 12 months\*\*
- PFOS reduction

## Purification system

- Chlorine removal

## Heating performance

- Heating method: Instant heating

## Filter specifications

- Filtration capacity: 2000 L
- Filter precision: RO: 0.0001 µm

## Input water conditions

- Input water temperature: 5-38°C °C

## General specifications

- Replacement filter cartridge: ADD541
- Applicable inlet water: Mains tap water
- Voltage and frequency: 220 V-240 V~, 50 Hz/ 60 Hz
- Product colour: Black
- Inlet water temperature: 5-38°C °C
- Water temperature: Ambient, 45, 85, 95 °C
- Water volume: 150, 200, 300, 500 ml
- Raw water tank: 4 L
- Product size: 200\*302\*404 mm
- UV sterilisation
- Filter lifetime indicator

# Highlights

## RO filtration removes 110 kinds of harmful substances

The innovative AquaShield All-in-One RO filter removes 110 kinds of harmful substances that may exist in tap water\*, delivering similar water quality to distilled water.

## Fresh hot water on demand in 3 seconds



Thanks to instant heating technology, freshly purified hot water is dispensed within seconds.

## 4 preset temperatures for your different needs

Precisely controlled temperatures for your different needs. No more waiting for it to cool down to a specific temperature. Whether you like coffee, tea or honey water, you can always make your favourite drink within seconds.

## 2000 L filtration capacity

The RO filter can filter up to 2000 litres of water, helping to save thousands of plastic bottles every year. So it's not only good for you, it's good for the environment too.

## 4 preset water volumes for your different needs

150 ml, 200 ml, 300 ml and 500 ml — you can always find the best volume setting for your favourite cups.

## Safety lock to prevent incorrect use or burning

When the output water temperature is above 45°C, the safety lock will be automatically activated to prevent incorrect use or scalding.

## ClearSmart intelligent system

Real-time filter status display reminds you to replace the filter when needed.

## Plug and play; no installation required

No installation needed for the dispenser. With a compact design, you can put it anywhere in your home.



Issue date 2024-08-19

Version: 3.3.1

EAN: 48 95244 61193 0

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\*\* Tested by 3rd-party testing agency under laboratory conditions.  
The contaminants or other substances reduced by this water filter  
are not necessarily in all users' water.

\*\*\* Tested by 3rd-party testing agency under laboratory conditions.