



Philips  
On tap water purifier

Micro Pure



WP3811

## Pure water made easy

with Micro Pure filter

Compact and easy to install water purifier that gives you pure water by removing bacteria, harmful organic compounds and chlorine while keeping all the good minerals in your water with a Micro Pure filter.

### Pure water

- Removes all bacteria, harmful organic compounds and chlorine

### Made easy

- Hi-flow with maximum rate of 2 liters per minute
- Pure Protect alert shows you when to replace the filter

### Simplicity

- Quick Fit tap adapters for easy installation on your tap
- Advanced Quick Twist mechanism for easy filter replacement

### Sustainability

- Maximum performance without the need of electricity

# PHILIPS

# Specifications

## Purification system

- Turbidity removal: 3000 liters or approx. 1 year
- Bacteria removal: 99.99 %
- VOC Removal
- Chlorine removal: >75 %

## Design specifications

- Color(s): white
- Materials: plastic
- Product weight: 230 g
- Product dimensions (L x W x H): 60 x 137 x 105 mm

## Filter specifications

- Filter lifetime: 2400 L or approx. 8 months
- Major filter components: hollow-fiber membrane, granular activated carbon GAC

## Input water conditions

- Min. input water pressure: 0.7 bar

- Max. input water temperature: 50 °C
- Max. input water pressure: 3.5 bar

## General specifications

- Accessories: 8 QuickFit tap-mounting adapters, PureProtect Alert
- Replacement filter cartridge: WP3911
- Water selection: filtered spray, unfiltered spray, unfiltered stream
- Water flow rate: 2 l/min
- Water flow rate: 5 °C

## Sustainability

- Packaging: > 90% recycled materials
- User manual: 100% recycled paper

## Country of origin

- Water purifier: Japan
- Replacement filter: Japan

# Highlights

## Micro Pure filter

The Micro Pure filter is a multi-filtration system that removes all bacteria, impurities and odors for clean, safe and tasty drinking water. It consists of a hi-tech hollow-fibre membrane, which contains more than 520 billion micro-pores for the efficient removal of 99.99% of all bacteria, and granular activated carbon which removes unpleasant chlorine, bad taste and odors. The filter also preserves all good minerals in the drinking water that are vital for human health.

## Pure Protect alert

The advanced and simple color-coded Pure Protect alert guides users to change the filter on time with maximum simplicity: when the membrane turns dark grey or rusty brown, it is time to replace the filter.

## Hi-flow

This compact water purifier has a maximum flow rate of 2 liters per minute, which makes little change to the normal flow rate of unfiltered water. By simply rotating the water selection lever, you also have a choice of either a stream or a spray of unfiltered water or spray of filtered water.

## Quick Fit tap adapters

This advanced water purifier comes with a number of tailor-made Quick Fit tap adapters, to help you having an easy and simple installation of your purifier in your tap. Real sense and simplicity.

## Quick Twist filter change

The advanced Quick Twist filter change mechanism makes changing the filter quick, easy and secure, bringing sense and simplicity to your water purifier.

## No energy consumption

Designed to operate without electricity while offering maximum performance. Supports sustainability.

