



Philips X-tremeVision Plus  
Headlight bulb

**Type of lamp: H1**

Pack of: 1  
12 V, 55 W



**LUM12972XVPB1**

## Take performance to the X-treme

Extra light, extra brightness

Philips X-tremeVision plus car bulbs are among the brightest you can buy. They outshine most other car lamps with up to 130% more brightness and a superior beam length. So you see further, react faster and drive safer.

### Increased brightness

- Exceptional beam quality and performance
- Great contrast for a comfortable drive

### High amount of light, high performance

- The safest, road-legal headlights
- One of the brightest bulbs: ultimate light performance
- See further and react faster with up to 130% more brightness
- Significantly whiter light to improve comfort and safety

### Best-in-class lifetime

- A lifetime of safety so you can see and be seen
- Performance means more light and longer lifetime

# PHILIPS

Headlight bulb  
Type of lamp: H1 Pack of: 1, 12 V,55 W

# Specifications

## Marketing specifications

- Expected benefits: More light
- Product highlight: Up to 130% brighter light

## Product description

- Application: Additional high beam, High beam, Low beam
- Base: PX26d
- Designation: H7 X-tremeVision Plus
- Homologation ECE
- Marking ECE: E1 22Z
- Range: X-tremeVision Plus
- Technology: Halogen
- Type: H7

## Lifetime

- Life time: 450 h

## Light characteristics

- Color temperature: 3500 K
- Lumens: 1500 ±15%

## Electrical characteristics

- Wattage: 55 W
- Voltage: 12 V

## Ordering information

- Order entry: 12972XVPB1
- Ordering code: 01624930

## Packaging Data

- EAN1: 8719018016249
- EAN3: 8719018016256
- Packaging type: B1
- 12NC: 928760135007

## Packed product information

- Gross weight per piece: 46 g
- Length: 9.5 cm
- Width: 3.5 cm
- Height: 12.9 cm
- Net weight per piece: 12 g
- Pack Quantity: 1
- MOQ (for professionals): 10
- Gross weight individual pack: 22.8 g

## Outerpack information

- Length: 20 cm
- Width: 20 cm
- Height: 14 cm
- Gross weight per piece: 460 g
- Gross weight [kg]: 0.319

LUM12972XVPB1/21

# Highlights

## The safest legal car lights



Philips X-tremeVision Plus is by far the safest, easiest and most efficient way to upgrade your car headlights within legal parameters. They are fully ECE certified.

## A lifetime of safety

Every potential failure of a spare part is a risk for you and your vehicle. This is especially true for headlights. Every broken headlight lamp reduces visibility and safety for you and the oncoming traffic. Philips X-tremeVision plus is optimized for a long and reliable lifetime. So you can see and be seen for longer than with any other high performance lamp.

## Exceptional beam quality

With a combination of more light and increased color temperature, Philips X-tremeVision plus qualifies as one of the best performance beams in the halogen segment.

## Extra light, extra lifetime

Philips X-tremeVision plus headlights are made for outstanding performance, producing up to 130% brighter light, without compromising on the lifetime. With up to 450 hours\*, Philips X-tremeVision's lifetime is significantly higher than competitor solutions in the more light category. (\*H4 and H7 tested at 13.2V standard voltage)

## Great contrast drives comfort

The increased color temperature in Philips X-tremeVision plus headlights (available in H1, H4 and H7) allows your eyes to focus better and perceive contrasts in the far distance. This makes driving after dark a far more comfortable and safe experience.

## One of the brightest bulbs

With its optimized high-precision filament geometry, up to 13 bar high pressure gas filling, high precision coating and high quality UV-Quartz glass, Philips X-tremeVision plus headlights set a new milestone in automotive lighting. They are engineered for the ultimate performance and uncompromising visibility.

## See further, react faster

Perfect illumination is especially important in the distance – usually between 75-100 meters in front of your vehicle. Philips X-tremeVision plus boosts your visibility with up to 130% more brightness. This helps you recognize obstacles and any potential dangers earlier than with most other halogen headlight lamps.

## Significantly whiter light

The bright white light (3.500 K) is significantly whiter than standard headlamps. The Philips patented gradient coating technology<sup>TM</sup> produces a more powerful light. So you can enjoy one of the brightest lighting performances and a highly comfortable night driving experience.



Issue date 2024-10-14

Version: 3.3.1

EAN: 87 19018 01624 9

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)