



Philips Unite LED 5000 Panels

Signage Solutions LED
Display

27"

Flip chip COB

Low power consumption



27HDL5118IP

Philips Unite LED 5000 Series panels

Quality. Style. Accessibility. Without compromise.

Your essential range of investment-friendly flip chip COB panels delivering on quality, resolution, and reliability, as well as efficiency. With low power consumption for reduced cost of ownership and an easy-to-maintain flat matt surface.

Flip chip COB dvLED panels

- Greater stability and reliability, plus higher definition.

Prewired cabinets for faster installation

- Prewired for power, with loop through for data included.

Low power consumption

- Supporting sustainability and energy savings.

Three year warranty as standard

- Activated out of the box for hassle free peace of mind.

Supports HDR10+ resolution

- Crystal clear content with vivid colours and brightness.

Specifications

Picture/Display

Brightness (nits): 600 nit
Brightness Uniformity: >=97%
Calibration(brightness/color): Color and Brightness
Color temperature default: 6500K±500
Contrast ratio (typical): 5000:1
Bit-depth(bit): 13
Frame frequency (Hz): 50-60
Refresh rate(Hz): 1920-3840 Hz
Colour temperature (K) adjust range (by software): 3000-10000
Viewing angle (°) H/V: 160°

Power

Input voltage: AC100~240V (50 & 60Hz)
Max cabinets power daisy chain: 16
BTU/M2 (BC): 1153
BTU/M2 (AC): 972
Cabinet Max Power consumption (W) (BC): <65
Cabinet Max Power consumption (W) (AC): <50
Cabinet Typical Power consumption (W) (AC): <30
Power consumption/M2 (W)(BC): 338
Power consumption/M2 (W)(AC): 285

Operating conditions

Temperature range (operation): -10 - 45 °C
Temperature range (storage): -40 - 60 °C
Humidity range (operation)[RH]: 10%-90%RH
Humidity range (storage) [RH]: 10%-70%RH
Working environment (indoor/outdoor): Indoor

Cabinet

Cabinet area (m2): 0.2052
Cabinet pixels (Dot): 57,600
Cabinet resolution (W x H): 320x180
Data connector: RJ45
Power connector: 3 pin connector

Receiving card brand: Novastar A8S-N
Weight (KG): 4.7±0.2
Cabinet diagonal (inch): 27.1"
Cabinet construction: Die cast
Cabinet Size (WxHxD in mm): 600x337.5x33.6

Module

LED type: COB
Pixel constitution: 1R1G1B Flip Chip
LED lifetime(Hrs): 100,000
Module resolution (WxH pixels): 80x90
Pixel pitch (mm): 1.875
Module size (WxH in mm): 150x168.75
LED Pole type: Common Anode
Weight(KG): 0.137
Black screen power saving

Accessories

LAN cable (type/length): RJ45 75cm/RJ45 15cm
Screws (type / length mm): Hex M6, 22mm
QSG (Quick Start Guide): Printed on carton

Miscellaneous

Warranty: 36 months
Regulatory approvals: CE, UKCA, FCC, ETL, RoHS, CCC, SASO

Packaging Data

Nett Weight (Product excluding accessories and packing in KG): <4.8kg
Packing Total weight Cardboard/paper (in Gram): 1100±100
Packing Total weight Plastics (LDPE/EPE/HDPE/PVC/ in Gram): 400±100
Package size (WxHxD mm): 822x461x99
Gross weight (full product, incl. accessories and packaging KG): 6.3±0.2

Highlights

Flip chip COB dvLED panels

Delivering on greater stability, reliability and visual performance, as well as enabling smaller pixel pitches for darker blacks, higher brightness, higher contrast and higher definition.

Stylish exterior and finishing

The Philips LED Unite 5000 Series comes with a rolling ripple exterior cabinet design and pre-wired for power for the tidiest cable management. Optional edge finishing is available in brushed anodised aluminium, with easy click functionality for fast installation.

12-bit colours and HDR10+

Supporting 12-bit colours and HDR10+ resolution, Philips LED Unite 5000 Series panels deliver crystal clear content with near perfect colour and brightness accuracy, delivering the deepest visual experiences.

