

PHILIPS



Car and truck
signaling bulb

Ultinon Pro7000 SI

LED-RED [≈P21W]

Number of bulbs: 2

12/24V, Intense Red

Advanced automotive system



LUM11498RU70X2/20

Enjoy lasting brightness for a safer drive.

Brighter, elegant signals

For a stylish and safe drive, upgrade to Philips Ultinon Pro7000 LED-RED [≈P21W] for your rear fog and stop lights. Their intense red color looks great and increases visibility so you can signal safely and stylishly.

Superior visibility for safer driving

- Signal your intent with brighter exterior lighting
- Instant safety information for other drivers
- Ergonomic design with 360° beam pattern

High-end, stylish signaling

- Upgrade your lights, upgrade your style.

Performance made to last

- Enhanced lifetime of up to 5,000 hours
- Aluminum heatsink to dissipate heat more efficiently

Simple plug-and-play replacement

- Easy to install and compatible with most car models
- Constant IC driver ensures electrical compatibility with mos
- Easy to install on your car

Ultinon Pro7000 SI

Car and truck signaling bulb

LUM11498RU70X2/20

Highlights

Powerful brightness

Signaling the intended movement of your vehicle is vital to your safety. To avoid collisions, other people need to know what you're doing. And when poor weather reduces visibility, the need for bright and vibrant signaling becomes even greater. Philips Ultinon Pro7000 LED signaling lights provide intense red light with 15 LEDs for your signals. They will help other drivers to see you better, which is vital for them to react sooner. The earlier you are seen, the safer your drive will be!

Instant-on technology

Compared to incandescent lamps, Philips Ultinon Pro7000 LEDs light up instantly to ensure that other drivers can react faster, keeping you safer.

Uniform light distribution

For your turn indicator, reverse, rear fog and stop signals, the Philips Ultinon Pro7000 LED gives you uniform light distribution. Its 360 angle ensures that the light is projected where you need it. Not only can you see more of the road, but other drivers can also see more of you.

Elegant LED light

While the main goal of exterior lighting is to help you see and be seen, there's no reason why you shouldn't look good at the same time. If you're wanting to upgrade your style without buying a newer car, replacing your exterior lighting with Philips Ultinon Pro7000 LED signals is a smart way to spend your money.

Lifetime of up to 5,000 hours

You want bright, stylish car lights but you don't want to keep replacing failed lamps. That's a major weakness of conventional bulbs - the more powerful the light, the shorter its lifespan. Even at a higher light intensity, LEDs last much longer. Philips Ultinon Pro7000 LED lights are built to last. Due to features such as high-end

LED technology and advanced heat-management systems, they last for up to 5,000 hours of operation.

Super-robust lamps with aluminum material

When operating, LEDs generate heat which reduces their brightness and overall lifespan. Philips Ultinon Pro7000 LED lights feature an aluminum heatsink which dissipates heat much faster than the plastic material used by low-cost, inferior-quality bulbs. That makes our lamps more robust and longer-lasting.

Ready, steady, installed!

Enjoy the plug-and-play experience: Philips Ultinon Pro7000 LED lights use the same standard caps as the conventional lamps on your car, enabling you to upgrade with no modification needed, so replacement is easy and quick.

Electrical compatibility with most cars and trucks

LED retrofit and conventional bulbs differ from one another in terms of wattage, composition, and power consumption. Replacing your conventional bulbs with other LEDs may prove problematic. Thanks to the built-in constant IC driver, Philips Ultinon Pro7000 bulbs can work within 9-32 volt systems and are electrically compatible with most cars and trucks. Canbus adapters are available as accessories for troubleshooting if needed. We sell a complete solution.

Polarity-free design

Enjoy the plug-and-play experience: the Philips Ultinon Pro7000 comes with polarity-free design, so you don't need to worry about the polarity during installation. It will save you time and make installation easier.

Specifications

Marketing specifications

Product highlight: Polarity-free, Automotive Grade LED, Powerful brightness, Uniform light distribution

Expected benefits: Brighter, elegant signals

Product description

Application: Stop lights and rear fog lights

Base: BA15S

Designation: P21W LED Red 11498 RU70 12/24V

X2

Homologation ECE: NO

Range: Ultinon Pro7000 SI

Technology: LED

Type: LED-RED [≈P21W]

Voltage: 12V+24V V

Lifetime

Life time: 5000 hrs

Light characteristics

Lumens: 115lm(12V), 120lm(24V)

Color temperature: RED

Electrical characteristics

Wattage: 2.6W(12V), 3.3W(24V) W

Voltage: 12V+24V V

Ordering information

Order entry: 11498RU70X2

Ordering code: 72681630

Packaging Data

EAN1: 6974260726816

EAN3: 6974260726823

Packaging type: X2

Packed product information

Length: 7,0 cm cm

Width: 2,5 cm cm

Height: 11,5 cm cm

Pack Quantity: 2 pcs

MOQ (for professionals): 10 packs

Gross weight per piece [g]: 40

Outerpack information

Length: 19,5 cm cm

Width: 15,5 cm cm

Height: 8,5 cm cm

Gross weight [kg]: 0,46

