



Philips Xperion 6000  
Pocket

300 lm Boost / 150 lm Eco

100 lm Spotlight  
Battery life: 3,5h (Eco: 7h)  
Compact and flexible



**X60POCKX1**

## Designed with you in mind

Advanced lighting performance that lasts

The compact, powerful Philips Xperion 6000 Pocket is perfect for confined spaces with an ultra-flexible 100 lm, 25cm hose spotlight. There's also a wide-beam light with 150 lm in Eco and 300 lm in Boost mode.

### Accessories available to upgrade your work lamp

- Smart solutions for charging your device

### Extended warranty

- Extend your warranty online to 3 years

### Handles tough conditions easily

- Resistant to impacts, water and solvents (IP65/IK07)

### Smart, ergonomic design

- Smart rotatable hook with magnet and ergonomic body
- Precision light with flexible hose spot

### See where others can't

- Long running time in different light modes
- Premium LED light with multiple outputs

# PHILIPS

# Highlights

## Multiple light modes



The powerful Xperion 6000 Pocket offers bright and homogenous LED lamps. The main beam features a dual light mode of 150 lm in Eco and 300 lm in Boost. This handy pocket torch is also equipped with a super flexible 100 lm hose spotlight, which is perfect for getting around obstacles.

## Illuminate your work



The Philips Xperion 6000 Pocket is equipped with a powerful 25cm hose spotlight to light any angle. The narrow and compact design is extremely convenient to help you work in confined small spaces. Slip Philips Xperion 6000 Pocket into your pocket and use it for a wide range of needs.

## Designed for resistance



Designed to handle tough work environments with IK07 shock resistance, water-resistant to IP65 standards, and a surface to withstand chemicals and workshop solvents, the Philips Xperion 6000 Pocket is built to last because we know that even the steadiest hands need the extra support.

## Light modes for multiple needs



The Philips Xperion 6000 Pocket is designed to be ready for action. A single charge provides enough energy for a full day's work: up to 7 hours in Eco mode, 3,5 hours in Boost mode, and 10 hours with the torch beam of the hose. Powered by a powerful Li-ion battery, the Xperion 6000 Pocket can be fully charged within 3,5 hours via USB-C, ensuring maximum usage of its bright LED light.

## Enables hands-free working



Designed with you in mind, the ergonomically shaped handle with anti-slip coating allows you to hold this work light securely. If you need both hands free for work, position the light securely thanks to the 360° rotatable, retractable hook and a strong magnet. The power button is located on the back to ensure the light does not glare directly at your eyes when you turn it on.

## Up to 3 years warranty



Benefit from Philips standard 2-year warranty plus 1 additional year<sup>1</sup>

## Upgrade your work light



To keep your work light to hand and ready to use, try the Philips Dock station. Placed on a table, it provides cordless charging for your lamp.<sup>2</sup> Find out more: [Philips.com/Xperion-6000](https://philips.com/Xperion-6000)

# Specifications

## Marketing specifications

- Product highlight: Compact and flexible
- Expected benefits: Designed with you in mind

## Product description

- Hands free options: Rotatable hook, strong magnet
- Hook: 360° rotatable
- Impact protection rating (IK): IK07
- Magnet: 1 magnet
- Materials & finishing: Robust ABS + Soft rubber
- Operating Temperature: -10°C to 40°C
- Range: Xperion 6000
- Technology: COB LED
- UV leak detector: No
- Ingress protection rating (IP): IP65
- Resistant to: Grease, oil, workshop solvents

## Light characteristics

- Beam angle: 110 degree
- Color temperature: 6000 K
- Beam angle (pointer): 60 degree
- Light output (pointer): 100 lumens
- Light output (eco): 150 lumens
- Light output (boost): 300 lumens

## Electrical characteristics

- Voltage: 3.7 V
- Power source: Rechargeable battery
- Battery capacity: 2000 mAh

- Battery run time (boost): Up to 3,5 hours
- Battery run time (eco): Up to 7 hours
- Battery type: Lithium battery
- Plug type: EU plug (not included for UK)
- Charging cable type: Type C USB
- Battery charging time: Up to 3,5 hours
- Wattage: 3W
- Battery run time (Pointer): Up to 10 hours

## Ordering information

- Order entry: X60POCKX1
- Ordering code: 01465831

## Packaging Data

- EAN1: 8719018014658
- EAN3: 8719018014665

## Packed product information

- Length: 6.5 cm
- Height: 15 cm
- Pack Quantity / MOQ: 6
- Weight with batteries: 324 g
- Cable length: 100cm USB cable, 5V 1A adaptor

## Outerpack information

- Length: 21.5 cm
- Width: 17 cm
- Height: 17 cm



Issue date 2024-11-12

Version: 10.0.1

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* 1 to be claimed on the Philips extended-warranty webpage

\* 2 Compatible with Xperion 6000 UV Pillar, Pillar, Slim, and Pocket