



Philips Ultinon Drive
5011L
10 Single Row LED
Lightbar

Sturdy one-piece body
IP69K waterproof
Corrosion-free stainless steel
Trouble-free operation



LUMUD5011LX1

Brilliant LED lighting for off-road adventures

Built for where you want to go

For drivers who demand the maximum of themselves and their machines, we offer Philips Ultinon Drive 5000 series LED lightbars. Exceptionally rugged, with unsurpassed illumination and beam focus, that can light the way.

Off-road auxiliary lights

- Trouble-free operation

Powerful brightness, Rugged performance

- Bright, long beam for superior visibility

Durable equipment for challenging conditions

- Corrosion-free, stainless-steel mounting brackets
- IP69K waterproof to master the elements
- Sturdy one-piece body for tough environments

PHILIPS

10 Single Row LED Lightbar

Sturdy one-piece body IP69K waterproof, Corrosion-free stainless steel, Trouble-free operation

Specifications

Product description

- Impact protection rating (IK): IK07
- Ingress protection rating (IP): IP68 & IP69K
- One-piece body design
- Operating Temperature: -40° F to 176° F
- Range: Ultinon Drive 5000
- Scratch resistant lens
- Technology: LED
- Accessories (optional): additional wiring kit
- corrosion-free brackets: yes, included
- Heat sink: 13-piece .06 in
- Material: Aluminum die-cast

Light characteristics

- Color temperature: 6500 K
- Effective lumen output: 2500 lumens

Electrical characteristics

- Voltage: 9-30 Volt DC

Ordering information

- Order entry: UD5011LX1
- GOC: 78002590

Packaging Data

- EAN1: 46678002595
- EAN3: 50046678002590

LUMUD5011LX1/50

Highlights

Superior visibility

The Philips Ultinon Drive 5000 series provides outstanding beam performance with brilliant illumination that extends up to 423 yards. With high lumen output coming from the powerful LEDs, the Ultinon Drive series provides ample visibility for faster reactions. Cool light color of 6500 Kelvin keep you focused without straining your eyes.

Sturdy one-piece body

Philips Ultinon Drive 5000 series lightbars are built with single-piece assemblies to withstand the toughest conditions. This also allows for excellent heat management and consistently high light output throughout your journey. Ultinon Drive 5000 series has an impact protection rating of IK07, to ensure it can withstand the hazards of aggressive offroading. Rugged polycarbonate lenses resist damage and scratches and the convenient DT connector guarantees a perfect connection.

Waterproof for durable light

With its ingenious screwless design, the Ultinon Drive 5000 series is rated IP68 and IP69K against dust, high temperature, and high pressure water. These lights will perform, wherever your road leads and whatever the weather. And they will be more than a match for any powerwasher you use to clean your ride after your adventures.

Corrosion-free brackets

Ultinon Drive 5000 series mounting brackets are made of highly corrosion resistant stainless steel. Built to withstand years of exposure in snow, ice, and salt air environments, these brackets and the entire lightbar will provide years of reliable service.

Trouble-free

Philips Ultinon Drive 5000 series lightbars are designed and tested to ensure they will function smoothly with your vehicle's electrical systems. They will not create electrical interference that might interfere with other vehicle functions.



Issue date 2024-11-12

Version: 3.3.1

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com