



Philips Xperion 6000
Slim

500 lm Boost / 250 lm Eco

150 lm Spotlight
Battery life: 4,5h (Eco: 7h)
Versatile and rotatable



X60SLIMX1

Designed with you in mind

Advanced lighting performance that lasts

The Philips Xperion 6000 Slim is versatile and ideal for narrow spaces. Featuring 250 lm in Eco and 500 lm in Boost mode, the unique 270° rotating light module will help you direct the powerful beam where you need it.

Accessories available to upgrade your work lamp

- Smart solutions for charging and finding your device

Extended warranty

- Extend your warranty online to 3 years

Handles tough conditions easily

- Resistant to impacts, water and solvents (IP54/IK07)

Smart, ergonomic design

- Smart rotatable hook with magnet and ergonomic body
- Precision, 270° rotatable light

See where others can't

- Long running time in different light modes
- Premium LED light with multiple outputs

PHILIPS

Slim

500 lm Boost / 250 lm Eco 150 lm Spotlight, Battery life: 4,5h (Eco: 7h), Versatile and rotatable

X60SLIMX1/10

Highlights

Multiple light modes



Featuring high-quality and bright LED light, the Philips Xperion 6000 Slim displays objects faithfully and vibrantly via a high-luminosity, wide-beam main source producing 250 lm in Eco and 500 lm in Boost mode. Use the spotlight source with a 150 lm torch beam to see better and spot the smallest details.

Light modes for multiple needs



The Philips Xperion 6000 Slim is designed to be ready for action. A single charge provides enough energy for a full day's work: up to 7 hours in Eco mode, 4,5 hours in Boost mode, and 9 hours with the torch beam. Powered by a powerful Li-ion battery, the Philips Xperion 6000 Slim can be fully charged within 4 hours

via USB-C, ensuring maximum usage of its bright LED light.

Illuminate your work



The Philips Xperion 6000 Slim is a versatile lamp ideal for illuminating narrow spaces. Thanks to its unique 270° rotating light module, you can easily position the light where you need it. There are multiple positions to help you work around small corners. This work light folds in half for compact storage.

Enables hands-free working



Designed with you in mind, the ergonomically shaped handle with anti-slip coating allows you to hold this work light securely. If you need both hands free for work, position the light securely thanks to the 360° rotatable,

retractable hook and a strong magnet. The power button is located on the back to ensure the light does not glare directly at your eyes when you turn it on.

Designed for resistance



Designed to handle tough work environments with IK07 shock resistance, water-resistant to IP54 standards, and a surface to withstand chemicals and workshop solvents, the Philips Xperion 6000 Slim is built to last because we know that even the steadiest hands need the extra support.

Up to 3 years warranty



Benefit from Philips standard 2-year warranty plus 1 additional year¹

Slim

500 lm Boost / 250 lm Eco 150 lm Spotlight, Battery life: 4,5h (Eco: 7h), Versatile and rotatable

X60SLIMX1/10

Specifications

Marketing specifications

- Product highlight: Versatile and rotatable
- Expected benefits: Designed with you in mind

Product description

- Hands free options: Rotatable hook, strong magnet
- Hook: 360° rotatable
- Impact protection rating (IK): IK07
- Magnet: 2 magnets
- Materials & finishing: Robust ABS + Soft rubber
- Operating Temperature: -10°C to 40°C
- Range: Xperion 6000
- Technology: COB LED
- UV leak detector: No
- Ingress protection rating (IP): IP54
- Resistant to: Grease, oil, workshop solvents

Light characteristics

- Beam angle: 100 degree
- Color temperature: 6000 K
- Light output (pointer): 180 lumens
- Light output (eco): 250 lumens
- Beam angle (pointer): 15°
- Light output (boost): 500 lumens

Electrical characteristics

- Voltage: 3.7 V
- Power source: Rechargeable battery
- Battery capacity: 2600 mAh

- Battery run time (boost): Up to 4,5 hours
- Battery run time (eco): Up to 7 hours
- Battery type: Lithium battery
- Plug type: EU plug (not included for UK)
- Charging cable type: Type C USB
- Battery charging time: Up to 4 hours
- Wattage: 5W
- Battery run time (Pointer): Up to 9 hours

Ordering information

- Order entry: X60SLIMX1
- Ordering code: 01467231

Packaging Data

- EAN1: 8719018014672
- EAN3: 8719018014689

Packed product information

- Length: 5.2 cm
- Height: 17.5 cm
- Pack Quantity / MOQ: 6
- Weight with batteries: 334 g
- Cable length: 100cm USB cable, 5V 1A adaptor

Outerpack information

- Length: 19.5 cm
- Width: 16.5 cm
- Height: 18 cm



Issue date 2024-11-12

Version: 12.12.1

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* 1 to be claimed on the Philips extended-warranty webpage

* 2 Compatible with Xperion 6000 UV Pillar, Pillar, Slim, and Pocket