

PHILIPS

LED-HL [≈H15]

Car lights

Type of lamp: H15

Direct-fit LED bulb

Compact design

6000 K cool white light

11580U2500CX



Upgrade. Drive. Enjoy.

Quick, easy installation

Upgrade your vehicle's headlights with the Philips Ultinon Access LED range. These bulbs are as quick and easy to install as halogen lamps! Enhance your lighting with 80% extra brightness** and enjoy the latest LED technology in your car.

Quick, easy installation

- Plug-and-play installation

Better light performance

- Better light-beam performance than halogen

Reliable Philips quality

- Automotive-standards compliant
- Long-lasting performance

Specifications

Marketing specifications

Product highlight: Direct-fit LED bulb

Expected benefits: Quick, easy installation

Product description

Application: High beam, DRL

Base: PGJ23t-1

Designation: LED H15 11580 U2500 12/24V CX

Designation LED Type: [≈H15]

Lifespan: 2000 hours

Marking ECE: no

Operating Temperature: -40°C / +85°C

Range: Ultinon Access HL

Technology: LED

Type: H15

Ingress protection rating (IP): IP65 (in headlamp)

Homologation ECE R37: no

Homologation ECE R10

Polarity free

Homologation: no

Diameter: 35.30 mm

Height: 77.50 mm

Light characteristics

Lumens: 1550/260 lm

Color temperature: 6000 K

Electrical characteristics

Wattage: 16W/2.6W

Voltage: 12/24 V

Ordering information

Order entry: 11580U2500CX

Ordering code: 02981250

Logistic data

Quantity in box: 2 pcs

Packaging Data

Packing: Box

EAN1: 8719018029829

EAN3: 8719018029836

Packaging type: CX

Packed product information

Net weight per piece: 52 g

Length [cm]: 9.5 cm

Width [cm]: 4.7 cm

Height [cm]: 7.9 cm

Net weight per pack: 104 g

Gross weight: 132 g

Outerpack information

Length: 20.2 cm

Width: 10.5 cm

Height: 10 cm

Packing: Carton

Quantity: 4 sets / 8 pcs

Gross weight per outerpack: 0,58 Kg

Highlights

Plug-and-play installation

With Philips Ultinon Access LED bulbs, installation is so quick and easy that retrofitting them is child's play! There's no need for compatibility checks or adapter rings: Philips Ultinon Access LED bulbs come with an ultra-compact body and an integrated IEC 60061 compatible base. Their direct-fit design features the same footprint as halogen bulbs, enabling straightforward installation in tight spaces. They fit easily into vehicles equipped with H15-type bulbs and ensure broad compatibility with most vehicle models*.

Beam outperforms halogen

Philips Ultinon Access LED bulbs are designed to offer better light-beam performance than halogen bulbs in a compact, universal design. Using the latest innovations in LED technology, they provide the same luminous flux as standard ECE halogen bulbs but significantly improve beam performance using less energy. Philips Ultinon Access LED bulbs provide drivers with better on-road vision, making it easier to spot obstacles and drive more safely.

Automotive-standards compliant

Technologically advanced, Philips lighting has been renowned in the automotive industry for over 100 years. Aware that the performance of our products depends on their compatibility with the demands of today's automotive environment, we design our products as closely as possible to industry standards. Our Philips Ultinon Access LED bulbs comply with EMI standards for electromagnetic interference. Precision-engineered to withstand the rigors of modern automotive life, our bulbs won't disrupt the operation of other vehicle components.

Long-lasting performance

Philips Ultinon Access LED bulbs are rigorously tested and checked to ensure long-term durability and long-lasting performance. Our range offers up to four times the life of a comparable halogen bulb and homogeneous light throughout the bulb's lifespan. The Philips warranty policy covers Philips Ultinon Access LED bulbs. Enjoy the best of today's technology with Philips Ultinon Access LED bulbs.

