

PHILIPS

AVENT

Microwave steriliser

Kills 99.9% of harmful germs

Sterilises in 2 minutes

Fits 4 Philips Avent bottles

Fits most microwaves

SCF281



Sterilise easily, anywhere

Wherever your day takes you, you can sterilise your baby's bottles and accessories quickly and safely. Our portable design is light enough to take with you and large enough to fit 4 bottles and accessories

Fits various bottle types and other products

- Sterilises pumps, soothers, cutlery as well as baby bottles
- Sterilises standard neck and wide neck baby bottles

Fast and effective microwave steam sterilisation

- Kills 99.9% of germs*
- Microwave steriliser ready in just 2 minutes
- Contents stay sterile for up to 24 hours

Lightweight, portable design

- Fits most microwaves on the market
- Lightweight design for sterile baby bottles on the go
- Stay cool safety clips to keep lid secure

Highlights

Sterilises in just 2 minutes



The microwave steam steriliser can be used to sterilise baby bottles and other products in just 2 minutes, killing 99.9% of germs and bacteria. The exact length of the cycle depends on the wattage of your microwave. 2 minutes at 1200–1850 W, 4 minutes at 850–1100 W, 6 minutes at 500–800 W.

Kills 99.9% of germs



The microwave steam steriliser is proven to kill 99.9% of germs and bacteria.*

Effective sterilisation



Contents remain sterile for up to 24 hours if the lid is unopened.

Works across bottle types



The steriliser sterilises standard neck and wide neck baby bottles. Up to 4 Philips Avent baby bottles can be sterilised at once.

Use for pumps, soothers too

The steriliser can be used to sterilise breast pumps, soothers, cutlery and other products as well as baby bottles.

Lightweight design for travel



The steriliser's lightweight and compact design makes it easy to take along with you wherever you go — holidays, visits to relatives, etc. Now you can always have sterilised baby bottles and other products within easy reach.

Fits most microwaves



The microwave steam steriliser has been designed to fit practically all microwaves on the market, keeping baby bottles and other products sterile wherever you are.

Stay cool safety clips



The microwave steam steriliser has stay cool safety clips to keep the lid secure. This ensures you can remove the steriliser safely from the microwave, keeping baby bottles and other products sterile and preventing the possibility of burning.

Specifications

Technical specifications

Sterilisation time: 2 min at 1200–1850 W, 4 min at 850–1100 W, 6 min at 500–800 W

Water capacity: 200 ml

Weight and dimensions

Dimensions: 166 (H), 280 (W), 280 (L) mm

Weight: 740 g

Country of origin

Made in: Poland

What is included

Microwave steam steriliser: 1 pcs

Tongs: 1 pcs

