

# PHILIPS

LED-FOG

[≈PS24W/PSX24W]

Car lights

Type of lamp: PS24W/PSX24W

Direct-fit LED bulb

Compact design

6000 K cool white light

11086U2500CX



## Upgrade. Drive. Enjoy.

### Quick, easy installation

Upgrade your vehicle's headlights with the Philips Ultinon Access LED range. These bulbs are as quick and easy to install as halogen lights! Enhance your lighting with 80% extra brightness\*\* and enjoy the latest LED technology in your car.

#### **Quick, easy installation**

- Plug-and-play installation

#### **Better light performance**

- Better light-beam performance than halogen

#### **Reliable Philips quality**

- Compliant with automotive standards
- Long-lasting performance

## Car lights

LED-FOG [≈PS24W/PSX24W]

LUM11086U2500CX/10

# Specifications

### Marketing specifications

**Product highlight:** Direct-fit LED bulb

**Expected benefits:** Quick, easy installation

### Product description

**Application:** Front fog

**Base:** PG20-3/7

**Designation:** LED PS24W/PSX24W 11086 U2500  
12 V 6 W CX

**Designation LED Type:** [≈PS24W/PSX24W]

**Lifespan:** 2000 hours

**Marking ECE:** No

**Operating Temperature:** -40°C/+85°C

**Range:** Ultinon Access FL

**Technology:** LED

**Type:** PS24W, PSX24W

**Ingress protection rating (IP):** IP65 (in headlight)

**ECE R37 certification:** No

**ECE R10 certification**

**Polarity free**

**Homologation:** No

**Diameter:** 41.4 mm

**Height:** 48.4 mm

### Light characteristics

**Lumens:** 750 lm

**Colour temperature:** 6000 K

### Electrical characteristics

**Wattage:** 6 W

**Voltage:** 12 V

### Ordering information

**Order entry:** 11086U2500CX

**Ordering code:** 02978250

### Logistic data

**Quantity in box:** 2 pcs

### Packaging Data

**Packing:** Box

**EAN1:** 8719018029799

**EAN3:** 8719018029805

**Packaging type:** CX

### Packed product information

**Net weight per piece:** 16 g

**Length [cm]:** 9.5 cm

**Width [cm]:** 4.7 cm

**Height [cm]:** 7.9 cm

**Net weight per pack:** 32 g

**Gross weight:** 61 g

### Outer pack information

**Length:** 20.2 cm

**Width:** 10.5 cm

**Height:** 10 cm

**Packing:** Carton

**Quantity:** 4 sets/8 pcs

**Gross weight per outer pack:** 0.53 kg

# Highlights

### Plug-and-play installation

With Philips Ultinon Access LED bulbs, installation is so quick and easy that retrofitting them is child's play! There's no need for compatibility checks or adapter rings: Philips Ultinon Access LED bulbs come with an ultra-compact body and an integrated IEC 60061 compatible base. Their direct-fit design features the same footprint as halogen bulbs, enabling straightforward installation in tight spaces. They fit easily into vehicles equipped with PS24W and PSX24W-type bulbs and ensure broad compatibility with most vehicle models\*.

### Beam outperforms halogen

Philips Ultinon Access LED bulbs are designed to offer better light-beam performance than halogen bulbs in a compact, universal design. Using the latest innovations in LED technology, they provide the same luminous flux as standard ECE halogen bulbs but significantly improve beam performance using less energy. Philips Ultinon Access LED bulbs provide drivers with better on-road vision, making it easier to spot obstacles and drive more safely.

### Compliant with automotive standards

Technologically advanced, Philips lighting has been renowned in the automotive industry for over 100 years. We are aware that the performance of our products depends on their compatibility with the demands of today's automotive environment, so we design our products as closely as possible to industry standards. Our Philips Ultinon Access LED bulbs comply with EMI standards for electromagnetic interference. Precision-engineered to withstand the rigours of modern automotive life, our bulbs won't disrupt the operation of other vehicle components.

### Long-lasting performance

Philips Ultinon Access LED bulbs are rigorously tested and checked to ensure long-term durability and long-lasting performance. Our range offers up to four times the life of a comparable halogen bulb and provides homogeneous light throughout the bulb's lifespan. The Philips warranty policy covers Philips Ultinon Access LED bulbs. Enjoy the best of today's technology with Philips Ultinon Access LED bulbs.

