

# PHILIPS

## Water dispenser

### Philips

Countertop

Reverse osmosis filtration

Ambient

6L tap water tank

ADD6926WH/37



## Crisp mineral water in various cups for every need

You will be amazed by this all-round RO filtration dispenser! Featuring customizable water volumes, built-in TDS display, and two portable filtered jugs, it's the perfect blend of style and convenience for your home.

### Cleaner water assured

- Aquaporin Inside® technology
- Adds minerals back into the water and balances pH
- Real-time water quality display gives you extra assurance
- Commonly-used volume settings at the touch of a button
- Portable purified water jug
- Large tap water tank avoids frequent water refill
- Plug and play; no installation required
- Adjustable drip tray for different sizes of cups
- Auto membrane flushing for optimal filtration performance
- Saves thousands of single-use plastic bottles every year
- BPA-free

# Highlights

## Aquaporin Inside<sup>®</sup> technology

Aquaporin Inside technology filters water better than before

## pH balance mineralization

Mineralization technology enhances purified water with beneficial minerals such as Sr, Ca, and Mg, refining the water taste and balancing the pH to alkaline.

## Water quality display

Thanks to the Total Dissolved Solids (TDS) display, you can be confident about the water you and your family drink.

## Commonly-used volume settings

You can always find a suitable water volume to fill your cups, mugs, bottles, or even jugs.

## Portable purified water jug

Thanks to the design of the portable purified water jug, you always have plenty of pure-tasting water to carry around for cooking and making drinks. You can even chill one jug with filtered water in the fridge for cold drinks, and keep the other jug placed in the water station for refilling.

## Large tap water tank

6L large water tank is perfect for family use, without the need of refilling it frequently.

## Installation free

The dispenser will start to work as soon as you connect the power and turn it on. No need to plumb in.

## Adjustable drip tray

The height of the drip tray can be easily adjusted to accommodate different sizes of cups, glasses, mugs, and bottles.

## Auto flushing

The auto-flushing program regularly cleans the membrane, ensuring the dispenser maintains optimal performance.

## Eco-friendly

Bottled water takes a significant toll on the environment, and also costly. With this water filtration system, you never need it again - you always have access to clean and fresh-tasting water.

## BPA-free

All parts that come into direct contact with water are made of BPA-free materials.

# Specifications

## Filtration performance

Chlorine reduction

Water hardness reduction

Total dissolved solids (TDS) reduction

Filtration precision: Down to 0.0001 micron

Mineralization

Stage of filtration: 6-stage

## Cooling Performance

Cooling capacity: 2.0L per hour

Cooling system: Compressor cooling

Cooling temperature: Down to 5°C

## Filter specifications

Filter lifetime: Up to 12 months

AQP RO filter: ADD583

## General specifications

Applicable inlet water: Municipal tap water

Product Dimension (LxWxH): 445\*230\*428 mm

Inlet water temperature: 5-38°C °C

Display: LED

Tap water tank: 6L capacity

Heating system: Instant heating

Inlet water pressure: 0.1-0.4MPa

UV disinfection

## Main parameters

Rated Power: 1500 W

Voltage and frequency: 110V/60Hz

