

# PHILIPS



True wireless  
headphones

1000 series

Clear call quality

13 mm drivers for punchy bass

Ergonomic design for comfort

IPX4 splash/sweat resistant



TAT1139WT

## Hear your sounds clearly

Hear tunes and calls properly. These True Wireless headphones use 13 mm drivers for rich sound and powerful bass and an AI mic for clear calls. With IPX4 splash and sweat resistance and a pocket-sized charging case for 26 hours play time.

### Up to 26 hours play time. Small charging case

- Up to 26 hours play time. Pocket-size charging case
- IPX4 splash and sweat resistant

### From favorite playlist to catch-up call

- Solid Bluetooth connection
- Warm, natural sound. Philips sound signature

### True wireless earbuds. Great value, great sound.

- Small and comfy earbuds that love a big bassline
- 13 mm drivers for great sound and powerful bass
- Clear calls. They'll hear what you're saying

## 1000 series

True wireless headphones

# Specifications

### Sound

**Frequency range:** 20 - 20,000 Hz  
**Speaker diameter:** 13 mm  
**Impedance:** 32 Ohm  
**Maximum power input:** 10 mW  
**Sensitivity:** 115 dB (1k Hz, 179mV)  
**Driver type:** Dynamic

### Connectivity

**Bluetooth version:** 5.4  
**Bluetooth profiles:** HFP, A2DP, AVRCP  
**Maximum range:** Up to 10 m  
**Supported codec:** SBC

### Outer Carton

**Length:** 30.00 cm  
**Number of consumer packagings:** 24  
**Width:** 16.00 cm  
**Gross weight:** 2.330 kg  
**Height:** 21.00 cm  
**GTIN:** 1 48 95229 15141 0  
**Nett weight:** 1.39 kg  
**Tare weight:** 0.94 kg

### Convenience

**Water resistance:** IPX4  
**Mono mode for TWS**  
**Type of controls:** Touch

### Power

**Number of batteries:** 3 pcs  
**Music play time:** 6 + 20 hour(s)  
**Talk time:** 6 hr  
**Charging time:** 2 hour(s)  
**Battery type(Charging case):** Lithium Polymer (built-in)  
**Battery type(Earbud):** Lithium Polymer (built-in)  
**Battery weight (Total):** 10.2 g  
**Battery capacity(Case):** 480 mAh  
**Battery capacity(Earbud):** 40 mAh

### Packaging dimensions

**Height:** 11.50 cm  
**Packaging type:** Carton  
**Type of shelf placement:** Hanging  
**Width:** 9.50 cm  
**Depth:** 3.60 cm  
**Number of products included:** 1  
**EAN:** 48 95229 15141 3  
**Gross weight:** 0.085 kg  
**Nett weight:** 0.058 kg  
**Tare weight:** 0.027 kg

### Accessories

**Quick Start Guide**  
**Charging case**  
**Charging cable:** USB-C cable, 200 mm

### Design

**Color:** White  
**Ear fitting:** In-ear  
**In-ear fitting type:** Open fit

### Telecommunication

**Microphone for call:** an AI mic each bud

### Dimensions

**Charging case dimension(WxDxH):** 5.23 x 2.54 x 5.61 cm  
**Earbud dimension(WxDxH):** 1.71 x 1.94 x 3.10 cm  
**Total weight:** 0.039 kg

### Voice assistant

**Voice assistant compatible:** Apple Siri, Google Assistant  
**Voice assistant activation:** Multi-Function touch  
**Voice assistant support**

TAT1139WT/97

# Highlights

### Small earbuds, great sound

These true wireless earbuds might be small, but you won't need to turn up the volume to get the best sound. Tap the left earbud to activate dynamic bass and you can enjoy the full power of your favourite basslines, even when listening quietly.

### 13 mm dynamic drivers

Hear your sounds the way they were meant to be heard. These headphones use custom design, 13 mm dynamic drivers to bring you an amazing listening experience. The drivers' large power capacity enhances dynamics and bass so you'll never miss a beat.

### Clear calls

Your voice will come through clearly when you're on a call. A dedicated mic picks up the sound of your voice while a noise-reduction algorithm quietsens some of the background noise from the world around you.

### Up to 26 hours play time

You get 6 hours play time from a full charge, and an extra 20 hours from the case. Pop the earbuds back in the case and they'll recharge fully in 2 hours. If you need a quick boost, just 15 minutes gives you an extra hour. The case can be charged via USB-C.

### IPX4 splash/sweat resistant

Never mind the weather, an IPX4 rating means these earbuds are splash resistant so they don't mind a little rain! Wearing them on a particularly hot day? They won't mind a little sweat either.

### Solid Bluetooth connection

Advanced Bluetooth connectivity gives you a more stable connection for seamless streaming. Enjoy that playlist or listen uninterrupted to your favorite podcast without annoying dips in the sound.

### Philips sound signature

Music to podcasts, you'll love what you hear! These true wireless earbuds feature large drivers, tuned to the Philips sound signature. Whatever you're into, you'll enjoy a warm, natural sound with deep bass.

