

PHILIPS

Water filter pitcher

Ultrafiltration

GAC + Hollow fiber membrane

1.5L tank for filtered water

AWP2970



Clean water made easy

Ultrafiltration system removes 99.9% bacteria

With multi-stage ultrafiltration system, this ergonomically designed water filter pitcher reduces chlorine, VOCs, herbicide, and up to 99.9% bacteria* for healthy and tasty drinking water, while retaining beneficial minerals.

Cleaner water

- Effectively reduces 99.9% bacteria

Made easy

- Digital timer reminds you when to replace the filter
- Dust-proof spout keeps water fresh and clean
- Ergonomic handle that is comfortable to hold and carry
- Simply discard the one-piece filter after use

Highlights

Digital timer

Digital timer reminds you when to replace the filter for the best result.

Ergonomic handle

Ergonomically designed, the handle is very comfortable to hold, which makes it easy to carry the pitcher.

One-piece disposable filter

Simply discard the one-piece filter when it reaches the end of lifetime. The one-piece design prevents secondary pollution.

3-stage ultrafiltration

The 3-stage ultrafiltration system consists of non-woven fabric, granular activated carbon and hollow fiber membrane, which effectively reduces chlorine, pesticides, chemicals, and up to 99.9% bacteria*. It also reduces particles down to 0.01 micron including microplastics for crisp and pure tasting water, while retaining beneficial minerals.

Dust-proof spout

By preventing dust from getting in through the water outlet, the dust-proof spout keeps the water fresh and clean.

Specifications

Filtration performance

Chlorine reduction

Bacteria removal: Yes, up to 99.9%*

Soluble lead reduction: N/A

Water hardness reduction: N/A

Filter specifications

Main filter media: Granular activated carbon/GAC, Hollow fiber membrane

Filtration capacity: 200L

Input water conditions

Input water temperature: 5-38 °C

Input water quality: Municipal tap water

Input water pressure: (atmospheric) 0-1 bar

General specifications

Replacement filter cartridge: AWP260/AWP261

Water flow rate: 0.15L/min

Country of origin

Pitcher: China

Filter: China

