

PHILIPS

Filter hand shower

AquaShield

ACF shower filter

Pressure-increasing design

Three spray modes

Easy clean silicone nozzle

ASH1516BK



Enjoy clean bath and lively life

With ACF filter, take a fresh shower

With a ACF shower filter, this hand shower can remove residual chlorine. And it has the pressure-increasing design and three kinds of water spray, delivers a clean and comfortable shower experience for you.

Three kinds of water spray meet different using

- Mixed spray for soft rinsing of the whole body
- Pressurized spray for refreshing tired skin
- Silk spray for comfortable facial massage

ACF shower filter

- With ACF filter

Convenient filter replacement

- Convenient filter replacement

Easy to remove limescale with liquid silicone nozz

- Easy to remove limescale with liquid silicone nozzle

Pressure-increasing design

- Microporous pressurization

Highlights

Mixed spray

Combination of pressurized spray and silk spray for realizing full coverage spray, it's suitable for soft rinsing of whole body.

Pressurized spray

116 microhole nozzles realize pressurized spray, relieve the trouble under low water pressure environment, and high dense spray can bring full relaxation to the skin.

Pressure-increasing design

The spray head adopts 116 microhole nozzles with a diameter of 0.45mm, which makes the water pressure increased and offers you a completely indulgent showering experience even in the low water pressure areas or in water consumption peak period.

Easy clean silicone nozzle

The nozzles are made of liquid silicone. The high-quality, tear-resistant liquid silicone is easy to rub by your fingers. You only need to rub the nozzles gently to remove the limescale.

ACF shower filter

ACF (activated carbon fiber) is an adsorption material made by carbonization, compared with traditional activated carbon, it has no rough hole, the activated carbon fiber is full of micropores with high specific surface area, its adsorption capacity is much better than that of granular activated carbon. Effectively remove residual chlorine, silt, rust, other large particle and odor.

Convenient filter replacement

Easy rotation 90 can be disassembled, without multi-layer thread, shower with assembly in place and disassembly marks, family members can easily disassemble.

Silk spray

Silk spray can release a radial dense spray to cover the face in multiple directions, it's ideal for facial massage.

Specifications

General specifications

Type: Filter type

Color: Black

Finishing: Electroplating

Shower head size: Ø120mm

Spray type: Pressurized/Silk/Mixed

Inlet water pressure: 0.05-0.5MPa

Switching mode: Lever

Connection type: G1/2

Filter specification

Filter model: ASH138/10

Main filter element: ACF filter

Lifespan: 1 month

Country of origin

Country of origin: China

Filter: China

System: China

Service

Warranty period: 2 year(s)

