

# PHILIPS

In-ear wired  
headphones

USB-C plug

10mm drivers

Close-back in-ear

TAE2146WT



## Dynamic bass

### Play music and talk

Powerful 10 mm drivers for dynamic bass and clear sound. In-line integrated mic and pick up button for convenient calls.

#### Use them for longer

- 3 interchangeable rubber ear caps for optimal fit in all ear

#### Always ready to go

- A 1.2m long cable that is ideal for outdoor use
- Rubberized cable relief enhances durability

#### Designed around you

- Integrated microphone & call button

#### Enjoy quality sound

- Perfect in-ear seal blocks out external noise

# Specifications

## Sound

Frequency range: 20 - 20 000 Hz

Speaker diameter: 10 mm

Impedance: 32 Ohm (+/-10%)

Maximum power input: 5 mW

Sensitivity: 104 dB (+/-3dB)

Driver type: Dynamic

## Connectivity

Cable Connection: Two-parallel, symmetric

Cable length: 1.2 m

Microphone: Built-in microphone

Type of cable: Copper

Finishing of connector: chrome-plated

## Outer Carton

Length: 35.50 cm

Number of consumer packagings: 96

Width: 29.00 cm

Gross weight: 4.230 kg

Height: 35.00 cm

GTIN: 1 48 95229 14923 3

Nett weight: 1.44 kg

Tare weight: 4.230 kg

## Convenience

Volume control

Type of controls: Button

Call control

Play/Pause

## Inner Carton

Length: 26.50 cm

Number of consumer packagings: 24

Width: 16.50 cm

Height: 16.00 cm

Nett weight: 0.360 kg

Gross weight: 0.920 kg

Tare weight: 0.560 kg

GTIN: 2 48 95229 14923 0

## Packaging dimensions

Packaging type: Carton

Type of shelf placement: Hanging

Number of products included: 1

EAN: 48 95229 14923 6

Height: 13 cm

Width: 5 cm

Depth: 3 cm

Gross weight: 0.030 kg

Nett weight: 0.015 kg

Tare weight: 0.015 kg

## Product dimensions

Height: 12.00 cm

Width: 3.00 cm

Depth: 2.00 cm

Weight: 0.014 kg

## Design

Color: White

Ear coupling material: Silicone

Ear fitting: In-ear

In-ear fitting type: Silicone ear tip

# Highlights

## Integrated microphone

With the integrated microphone and call button you can use this Philips headset for music as well as calls from your mobile phone. Enjoy handsfree calling, while easily accepting and ending calls from your headset.

## Perfect in-ear seal

The Super-small speaker drivers of these Philips earphones fit comfortably inside the ear and thanks to the exceptionally snug fit the outside noise is sealed out for high-intensity listening experience.

## 1.2m cable

The ideal cable length to give you the freedom to put your audio device where you want.

## Rubberized cable relief

To extend product life, soft rubber between headphones and cable protects cable connection from damage through repeated bending.

## For optimal fit in all ears



With a choice of 3 interchangeable ear caps from size small to large, surely there is a pair that makes these Philips earphones fit your ear perfectly.

