

# PHILIPS

## Over-ear wireless headphones

Noise Canceling Pro

Lightweight over-ear headphones

Natural sound. Dynamic Bass

Up to 60 hours play time

TAH7508BK



## Immerse freely

Work or play, flow through your days with these wireless noise-canceling headphones! Adaptive noise cancellation and a comfy over-ear fit keep you immersed. You get rich, detailed sound, and there's a low lag setting for games and movies.

### **Over-ear wireless headphones. Immerse in style**

- Immerse with Noise Canceling Pro
- Light, comfy, foldable—and stylish!
- Great sound even at low volume with Dynamic Bass

### **Always ready for work and play**

- Up to 60 hours play time (45 with noise canceling on)
- Clear calls. They'll hear what you're saying
- Solid Bluetooth multipoint connection

### **Rich natural sound and handy companion app**

- Philips Headphones app. Personalize settings and controls
- Warm, detailed, natural. Philips sound signature
- A quick 15-minute charge provides 3 hours of playback

# Highlights

## Noise Canceling Pro

Adaptive noise cancellation quickly reacts to your surroundings to suppress external noise, including wind, in real time. If you want to hear what's going on around you, Awareness Mode lets outside sounds back in. Quick Awareness enhances voices, so you can have a conversation without removing your headphones.

## Lightweight and comfy

The round ear-cup mounts and sleek frame give these over-ear headphones a distinctive sense of style. Memory foam ear-cup cushions keep you comfortable through long listening sessions—and the ear cups fold flat and swivel inward for easy storage in your pocket or bag.

## Great sound. Dynamic Bass

You'll enjoy rich sound from the 40 mm drivers, and good passive noise isolation from the over-ear fit. To enjoy the full power of your favorite

basslines without turning up the volume, simply activate Dynamic Bass via the multifunction button or the Philips Headphones app.

## Up to 60 hrs (with ANC off)

You get well over a day of listening even if you have noise cancellation turned on. A full charge takes just 2 hours via USB-C, and a quick 15-minute charge gives you an extra 3 hours. You can also use a USB-C cable to plug into any smart device with a USB-C port.

## Clear calls

Your voice will come through clearly when you're on a call. A dedicated mic picks up the sound of your voice while a noise-reduction algorithm quietens some of the background noise from the world around you.

## Solid Bluetooth connection

Advanced Bluetooth connectivity gives you a more stable connection for seamless streaming, and you can connect to two Bluetooth devices

(iOS or Android) at the same time. Enjoy that playlist or listen uninterrupted to your favorite podcast without annoying dips in the sound.

## Philips Headphones app

Ever forget to turn off your headphones? Set a timer on our companion app and they'll power down automatically. The app also lets you manage connected devices or turn adaptive noise cancellation off and take control of the levels yourself. Plus, there's a range of preset sound styles: 'Voice' is ideal for podcasts!

## Philips sound signature

Music to podcasts, these wireless headphones make the most of the sounds you love! You'll enjoy warm, detailed sound with rich bass from the large drivers, which are tuned to the Philips sound signature.

# Specifications

## Sound

Acoustic system: Closed  
Frequency range: 7 - 40,000 Hz  
Impedance: 32 Ohm  
Sensitivity: 96 dB (1k Hz)  
Speaker diameter: 40 mm  
Maximum power input: 30 mW  
Driver type: Dynamic  
Hi-Res Audio

## Connectivity

Bluetooth version: 5.2  
Bluetooth profiles: A2DP, AVRCP, HFP  
Maximum range: Up to 10 m  
Multipoint connection  
Supported codec: SBC, AAC  
Headphone socket: 3.5 mm

## Outer Carton

Length: 21.6 cm  
Number of consumer packagings: 3  
Width: 21 cm  
Gross weight: 1.742 kg  
Height: 26.3 cm  
GTIN: 1 48 95229 14021 6  
Nett weight: 1.12 kg  
Tare weight: 0.622 kg

## Convenience

Automatic power off  
Volume control  
Philips Headphones app support  
Firmware updates possible  
Type of controls: Button

## Power

Number of batteries: 1 pcs  
Talk time: 35 hr  
Charging time: 2 hour(s)  
Music play time (ANC on): 45 hour(s)  
Music play time (ANC off): 60 hour(s)  
Fast charging time: 15 mins for 3 hrs  
Battery weight (Total): 12.4 g  
Battery capacity(Headphones): 600 mAh  
Battery type(Headphones): Lithium Polymer (built-in)

## Packaging dimensions

Height: 25.5 cm  
Packaging type: Carton  
Type of shelf placement: Hanging  
Width: 19.45 cm  
Depth: 6.2 cm  
Number of products included: 1  
EAN: 48 95229 14021 9  
Gross weight: 0.5 kg  
Nett weight: 0.303 kg  
Tare weight: 0.197 kg

## Product dimensions

Height: 21 cm  
Width: 18.7 cm  
Depth: 5 cm  
Weight: 0.271 kg

## Accessories

Audio cable: 3.5mm stereo cable, L=1.2m  
Quick Start Guide  
Charging cable: USB-C cable, 500mm

## Design

Color: Black  
Wearing style: Headband  
Foldable design: Flat/Compact fold  
Ear coupling material: Fabric  
Ear fitting: Over-ear  
Earcup type: Closed-back

## Telecommunication

Microphone for call: 1 mic

## ANC features

ANC technology: Hybrid  
Awareness mode  
Microphone for ANC: 4 mic  
ANC (Active Noise Canceling)

## Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant  
Voice assistant activation: Press ANC button  
Voice assistant support

