

PHILIPS

Filter hand shower

AquaShield

ACF shower filter

Pressure-increasing design

Three spray modes

Easy clean silicone nozzle

ASH1516BK



Enjoy a clean bath and a lively life

With an ACF filter, take a fresh shower

With an ACF shower filter, this shower head can remove residual chlorine. Plus, it has a pressure-increasing design and three water spray modes, delivering a clean and comfortable shower experience for you.

Three water spray modes for different uses

- Silk spray for comfortable facial massage
- Mixed spray for soft rinsing of the whole body
- Pressurised spray for refreshing tired skin

ACF shower filter

- With ACF filter

Convenient filter replacement

- Convenient filter replacement

Easy to remove limescale with liquid silicone nozzle

- Easy to remove limescale with liquid silicone nozzle

Pressure-increasing design

- Microporous pressurisation

Highlights

Silk spray

Silk spray can release a radial dense spray to cover the face in multiple directions, ideal for facial massage.

Convenient filter replacement

Easy rotation 90 can be disassembled, without multi-layer threads, shower with assembly in place and disassembly marks, so that family members can easily disassemble.

Mixed spray

Combination of pressurised spray and silk spray to create a full-coverage spray, suitable for soft rinsing of the whole body.

ACF shower filter

ACF (activated carbon fibre) is an adsorption material made by carbonisation, compared with traditional activated carbon, it has no rough hole, the activated carbon fibre is full of micropores with high specific surface area, its adsorption capacity is much better than that of

granular activated carbon. Effectively remove residual chlorine, silt, rust, other large particles and odour.

Easy clean silicone nozzle

The nozzles are made of liquid silicone. The high-quality, tear-resistant liquid silicone is easy to rub by your fingers. You only need to rub the nozzles gently to remove the limescale.

Pressure-increasing design

The spray head has 116 microhole nozzles with a diameter of 0.45 mm, which makes the water pressure increase and offers you a completely indulgent showering experience even in the low water pressure areas or in water consumption peak periods.

Pressurised spray

116 microhole nozzles create a pressurised spray to solve difficulties under low water-pressure environments, and the high density spray brings full relaxation to the skin.

Specifications

General specifications

Type: Filter type

Colour: Black

Finishing: Electroplating

Shower head size: Ø120mm

Spray type: Pressurised/Silk/Mixed

Inlet water pressure: 0.05-0.5 MPa

Switching mode: Lever

Connection type: G1/2

Filter specification

Filter model: ASH138/10

Main filter element: ACF filter

Lifespan: 1 month

Country of origin

System: China

Country of origin: China

Filter: China

Service

Warranty period: 2 year(s)

